### **SAMSUNG**

### SPLIT-TYPE AIR CONDITIONER

#### INDOOR UNIT

MODEL CODE AR07CSDAFWKNCV AR09CSDABWKNCV AR12CSDABWKNCV AR15CSDAFWKNCV AR15CSDABWKNCV AR18CSDABWKNCV AR24CSDABWKNCV AR07CSFCMWKNCV AR09CSFCMWKNCV AR12CSFCMWKNCV AR15CSFCMWKNCV AR18CSFCMWKNCV AR24CSFCMWKNCV AR24CSDADWKNCV

#### **OUTDOOR UNIT**

AR09CSDABWKXCV AR12CSDABWKXCV AR15CSDABWKXCV AR18CSDABWKXCV AR24CSDABWKXCV AR09CSFCMWKXCV AR12CSFCMWKXCV AR15CSFCMWKXCV AR18CSFCMWKXCV AR24CSFCMWKXCV AR09CSDACWKXCV AR12CSDACWKXCV AR15CSDACWKXCV AR18CSDACWKXCV AR24CSDACWKXCV AR18CSDADWKXCV AR18CSDAEWKXCV AR24CSDAEWKXCV

# SERVICE Manual

### **AIR CONDITIONER**



#### **CONTENTS**

- 1. Precautions
- 2. Product Specifications
- 3. Alignment and Adjustments
- 4. Disassembly and Reassembly
- 5. ASSY CONTROL
- 6. Wiring Diagram
- 7. PCB Diagram
- 8. Operating Instructions
- 9. Troubleshooting
- 10.Block Diagram
- 11. Reference Sheet

Contents	
1. Precautions	4
1-1 Installing the air conditioner	4
1-2 Power supply and circuit breaker	4
1-3 During operation 1-4 Disposing of the unit	4 5
1-4 Others	5
2. Product Specications	6
2-1 The Feature of Product	6
2-2 Product Specifications 2.7 The comparative specifications of product	7 9
2-3 The comparative specifications of product 2-4 Accessory and option specifications	13
3. Alignment and Adjustments	14
3-1 Test mode	14
3-2 Display Error and Check Method	15
3-3 Setting Option Setup Method	17
4. Disassembly and Reassembly	22
4-1 Indoor Unit	23
4-2 Outdoor Unit	33
5. ASSY CONTROL	51
5-1 ASSY KIT INDOOR CODE DB92-05191G, J	51
5-2 ASSY KIT INDOOR CODE DB92-05201F 5-3 ASSY KIT OUTDOOR CODE DB92-05037H,J	52 53
5-4 ASSY KIT OUTDOOR CODE DB92-05037K	54
6. Wiring Diagram	55
6-1 Indoor unit	55
6-2 Outdoor unit	56
7. PCB Diagram	58
7-1 Indoor Main PCB CODE DB92-05043J	58
7-2 Outdoor Main PCB CODE DB92-04837U, V	59
7-3 Outdoor PCB Inverter CODE DB92-04838Q, R 7-4 DISPLAY PCB	61 63
7-5 Wire connecting the indoor unit terminal blocks	64
7 3 WITE CONTINUE THE INCOME WHILE TENTINAL DIOCKS	04

#### **Contents** 8. Operating Instructions 65 8-1 Name of Each Part 65 8-2 Wireless Remote Control-Buttons and Display 66 9. Troubleshootin 68 9-1 Items to be checked First 68 9-2 Communication Error 69 9-2-1 Communication Error 69 9-2-2 Indoor temperature sensor Error 70 9-2-3 Indoor fan motor speed detecting error (BLDC fan) 71 9-2-4 Outdoor temperature sensor error 72 9-2-5 Outdoor Cond temperature sensor error 73 9-2-6 Outdoor Discharge temperature sensor error 74 9-2-7 Operation condition secession error 75 9-2-8 EEPROM error/OTP error 76 9-2-9 Outdoor Fan motor error 77 9-2-10 Compressor starting error 78 9-2-11 Compressor wire missing error/rotation error 79 9-2-12 Current sensor error/Input current sensor error 80 9-2-13 O.C(Over Current) error 81 9-2-14 No power outdoor (Initial Diagnosis) (Not displayed) 83 9-2-15 When the Up/Down, Left/Right, Grill louver motor does not operate 84 9-2-16 When the remote control is not receiving 85 9-2-17 Smart Install error 86 9-2-18 Outdoor OLP over temperature error (One way Inverter Only) 87 9-2-19 EEV or VALVE CLOSE error (C422) 88 10. Block Diagram 89 10-1 Indoor unit 89 10-2 Outdoor unit 90 11. Reference Sheet 93 93 11-1 Low Refrigerant Pressure Distribution 93 11-2 Pressure & Capacity mark 11-3 Q & A for Non-trouble 94 11-4 Cleaning /Filter Change 97 11-5 Installation 100 11-6 Installation Diagram of Indoor Unit and Outdoor Unit 101 11-7 Reference sheet 103

### 1. Precautions

### 1-1 Installing the air conditioner

- Uses should not install the air conditioner by themselves. Ask the dealer or authorized company to install the air conditioner except window-type air conditioner in U.S.A and Canada.
- If you don't install the air conditioner properly, it may cause a fire, a water leakage or an electric shock.
- You must install the air conditioner according to the national wiring regulations and safety regulations.
- Install the indoor unit higher than 2.5m from the floor to avoid the injury caused by the operation of the fan. (except the window-type air conditioner)
- The manufacturer is not responsible for any accidents or injury caused by an incorrect installation.
- When installing the built-in type air conditioner, keep all electric cables such as the power cable and the connection cord in pipes, ducts, or cable channels to protect them from the danger of impact or any other incidents.

### 1-2 Power supply and circuit breaker

- If the power cord of the air conditioner is damaged, it must be replaced by the manufacturer or a qualified person in order to avoid a hazard.
- The air conditioner must be plugged into an independent circuit if applicable or connect the power cable to the auxiliary circuit breaker. An all pole disconnection form the power supply must be incorporated in the fixed wiring with a contact opening of 3mm.
- Do not extend an electric cord to the air conditioner.
- The air conditioner must be plugged in after you complete the installation.

### 1-3 During operation

- Do not repair the air conditioner at your discretion. It is recommended to contact a service center directly.
- Never spill any kind of liquid on the air conditioner. If this happens, turn off the air conditioner and contact an authorized service center.
- Do not insert anything between the airflow blades to prevent damage of the inner fan and consequent injury. Keep children away from the air conditioner.
- Do not place any obstacles in front of the air conditioner.
- Do not spray any kind of liquid into the indoor unit. If this happens, turn off the air conditioner and contact a service center.
- Make sure that the air conditioner is well ventilated at all times. Do not place a cloth or other materials over it.
- Remove the batteries if you don't use the remote control for a long time. (If applicable)
- Use the remote control within 7 meters from the indoor unit. (If applicable)

### 1-4 Disposing of the unit

- Before the throwing out the air conditioner, remove the batteries from the remote control.
- When you dispose of the air conditioner, consult your dealer. If pipes are removed incorrectly, refrigerant may blow out and cause air pollution. When it contacts with your skin, it can cause skin injury.
- The package of the air conditioner should be recycled or disposed of properly for environmental reasons.

#### 1-5 Others

- Never store or load the air conditioner upside down or sideways to prevent the damage to the compressor.
- Young children or infirm persons should be always supervised when they use the air conditioner.
- Max current is measured according to IEC standard for safety.
- Current is measured according to ISO standard for energy efficiency.



### 2. Product Specications

### 2-1 The Feature of Product

### ◆ Fast cooling

If you want the strong and cool air, just select Fast function! It will get you the strongest air!

### WindFree Cooling

Use the WindFree Cooling function to enjoy a mild breeze coming through fine holes in the WindFree panel instead of air coming directly through the air flow blades.

#### ◆ Eco

Use the Single User function when you're along at home. Aside from energy savings from the inverter technology, the Single User Mode will further minimize your energy consumption and reduce your electricity bill by adjusting the maximum operating capacity of the compressor.

### ◆ Easy Filter

There is no grille to remove before separating the filter from the air conditioner! Therefore, filter can be cleaned easily and more frequently. Constant filter cleaning will prevent dust from entering the product or accumulating on the filter.

### good'sleep function

good'sleep function will allow you to have deep, good night'sleep by adjusting the temperature, fan speed and air flow direction.

#### ◆ Smart Install

When the installation is done, your product will examine itself through trial operation to check if it was installed properly.

#### Easy Installation

It's so easy to install! You can easily hang the product on the wall and connect the pipes and wires by opening the cover on the bottom of the product. Now you won't have to tilt the product to connect the pipe and the wires!

	Model		AR09CSDABWKNCV	AR12CSDABWKNCV	AR15CSDABWKNCV	AR18CSDABWKNCV
Rating	Mode	Unit	Wall-mounted	Wall-mounted	Wall-mounted	Wall-mounted
	T1 Cool	Btu/h	9000	12000	15000	18000
Capacity	T3 Cool	Btu/h	-	-	-	-
	Heat	Btu/h	11000	12000	15000	20000
	T1 Cool	W	580	890	1070	1385
Power Input	T3 Cool	W	-	-	-	-
	Heat	W	730	830	980	1570
	T1 Cool	А	2.8	4.2	5	6.2
Current	T3 Cool	А	-	-	-	=
	Heat	-	3.4	3.8	4.5	7
	EER	Btu/hW	15.50	13.50	14.00	13.00
Efficiency	-		-	-	-	-
	COP	W/W	15.05	14.45	15.30	12.75
Dehumid	lifying	l/hr.	2.5	2.5	2.5	2.5
DI . (	IDU	-	QF2	QF2	QF3	QF3
Platform	ODU	-	N-SI	N-SI	P-520	P-520
	Main	-	Φ7, ( 2R*10S+1R*4S )*660mm, (H1.3+H1.3), N.G.S, 1by2	Φ7, ( 2R*10S+1R*4S )*660mm, (H1.3+H1.3), N.G.S, 1by2	Φ7, ( 2R*10S+1R*4S )*825.5mm, (H1.3+H1.3), Hydrophilic, 4by4	Φ7, ( 2R*10S+1R*4S )*825.5mm, (H1.3+H1.3), Hydrophilic, 4by4
Evap	Sub	-	Φ7, ( 2R*6S+1R*4S )*660mm, (H1.3+H1.3), N.G.S : (S2-3)	Φ7, ( 2R*6S+1R*4S )*660mm, (H1.3+H1.3), N.G.S : (S2-3)	Φ7, ( 2R*6S+1R*4S )*825.5mm, (H1.3+H1.3), Hydrophilic : (S3-6)	Φ7, ( 2R*6S+1R*4S )*825.5mm, (H1.3+H1.3), Hydrophilic : (S3-6)
Cond	Main	-	Φ7W, 2R*24S*850/825mm, Corrugate1.5, N.G.S, 4by4by2	Φ7W, 2R*24S*850/825mm, Corrugate1.5, N.G.S, 4by4by2	Φ7W, 2R*36S*906.8mm, Corrugate1.5, N.G.S, 5by5by1	Φ7W, 2R*36S*906.8mm, Corrugate1.5, N.G.S, 5by5by1
	Sub	-	=	-	-	-
	Model	-	KTN130D42UFR	KTN130D42UFR	KTN150D42UFR	UG8TH8265FEW
Comp	OLP	-	-	-	-	-
	Code	-	DB31-00636A	DB31-00636A	DB31-00637A	DB31-00637A
Motor In	Name	-	-	-	=	=
	Code	-	DB31-00642C	DB31-00642C	DB31-00579A	DB31-00579A
Motor Out	Name	-	-	-	-	-
Expansion	Φ*L	-	Ф1.4	Ф1.4	Φ1.65	Φ1.65
<u> </u>	type	-	R410A	R410A	R410A	R410A
Refrigerant	charge	g	1150 g	1150 g	1600 g	1800 g
SVC Valve	Liquid / Gas	-	Ф6.35/Ф9.52	Ф6.35/Ф9.52	Ф6.35/Ф12.7	Ф6.35/Ф12.7
Tube	Dis. / Suc.	-	Ф9.52/Ф12.7	Ф9.52/Ф12.7	Ф9.52/Ф12.7	Ф9.52/Ф15.88
Drain hose	D*L	mm	20*550	20*550	20*550	20*550
4-WAY	V/V	-	-	-	-	-
Power S	upply	V/Hz/Φ	208-230/60/1	208-230/60/1	208-230/60/1	208-230/60/1
Climate	Class	-	T1	T1	T1	T1
Noise	IDU UT,T	dB	41 dB↓	43 dB↓	46 dB↓	48 dB↓
1 10130	ODU	dB	51 dB↓	53 dB↓	57 dB↓	57 dB↓
Net Size	IDU	mm	889*299*215	889*299*215	1055*299*215	1055*299*215
(W*D*H)	ODU		790*548*285	790*548*285	880*798*310	880*798*310
Weight	IDU	kg	10.1	10.1	11.5	11.5
vveigitt	ODU	Kg	32.4	32.4	49.0	55.6
	Cooling	IDU	61 ~ 90 °F	61 ~ 90 °F	61 ~ 90 °F	61 ~ 90 °F
Operation	Cooting	ODU	14 ~ 115 °F	14 ~ 115 °F	14 ~ 115 °F	14 ~ 115 °F
range	Heating	IDU	81 °F or less	81 °F or less	81 °F or less	81 °F or less
	ricating	ODU	-5.1 ~ 75 °F	-5.1 ~ 75 °F	-5.1 ~ 75 °F	-5.1 ~ 75 °F

	Model		AR24CSDABWKNCV	AR09CSFCMWKNCV	AR12CSFCMWKNCV	AR15CSFCMWKNCV	
Rating	Mode	Unit	Wall-mounted	Wall-mounted	Wall-mounted	Wall-mounted	
	T1 Cool	Btu/h	21000	9000	12000	15000	
Capacity	T3 Cool	Btu/h	-	-	-	-	
	Heat	Btu/h	25000	11000	12000	15000	
	T1 Cool	W	1680	692	995	1250	
Power Input	T3 Cool	W	-	-	-	-	
	Heat	W	2000	865	998	1110	
	T1 Cool	А	7.6	3.1	4.8	5.6	
Current	T3 Cool	А	-	-	-	-	
	Heat	-	9	4.2	4.6	5.2	
	EER	Btu/hW	12.50	13	12	12	
Efficiency	-		-	-	-	-	
	COP	W/W	12.50	12.70	12.50	13.50	
Dehumio	difying	l/hr.	2.5	2.5	2.5	2.5	
	IDU	-	QF3	QF1	QF1	QF3	
Platform	ODU	-	UB1	N-SI	N-SI	Q-480	
	Main	-	Φ7, ( 2R*10S+1R*4S )*825.5mm, (H1.3+H1.3), Hydrophilic, 4by4	Φ7, 2R*9(10)S*591mm, H1.3, N.G.S, 1by2	Φ7, 2R*9(10)S*591mm, H1.3, N.G.S, 1by2	Φ7, 2R*10S*825.5mm, H1.3, N.G.S, 4by4	
Evap	Sub	-	Φ7, ( 2R*6S+1R*4S )*825.5mm, (H1.3+H1.3), Hydrophilic : (S3-7)	Φ7, 2R*5(6)S*591mm, H1.3, N.G.S : (S1-5)	Φ7, 2R*5(6)S*591mm, H1.3, N.G.S : (S1-5)	Φ7, 2R*5(6)S*826mm, H1.3, N.G.S : (S3-3)	
Cond	Main	-	Φ7W, 2R*46S*950mm, Cor- rugate1.5, N.G.S, 8by8	Φ7W, 2R*24S*850/825mm, Corrugate1.5, N.G.S, 4by4by2	Φ7W, 2R*24S*850/825mm, Corrugate1.5, N.G.S, 4by4by2	Φ7W, 2R*28S*906.8mm, Corrugate1.5, N.G.S, 4by4by1	
	Sub	-	-	-	-	-	
	Model	-	UG8TH8265FJW	KTN130D42UFR	KTN130D42UFR	UG9TK3150FE4	
Comp	OLP	-	-	-	-	-	
Mataula	Code	-	DB31-00637A	DB31-00694A	DB31-00694A	DB31-00636A	
Motor In	Name	-	-	-	-	-	
	Code	-	DB31-00579A	DB31-00642C	DB31-00642C	DB31-00642C	
Motor Out	Name	-	-	-	-	-	
Expansion	Φ*L	-	Ф1.65	Ф1.4	Ф1.4	Ф1.65	
5.61	type	-	R410A	R410A	R410A	R410A	
Refrigerant	charge	g	2500 g	1000 g	1000 g	1300 g	
SVC Valve	Liquid / Gas	-	Ф6.35/Ф15.88	Ф6.35/Ф9.52	Ф6.35/Ф9.52	Ф6.35/Ф12.7	
Tube	Dis. / Suc.	-	Ф9.52/Ф15.88	Ф9.52/Ф12.7	Ф9.52/Ф12.7	Ф9.52/Ф12.7	
Drain hose	D*L	mm	20*550	20*550	20*550	20*550	
4-WAY	V/V	-	-	-	-	-	
Power S	upply	V/Hz/Φ	208-230/60/1	208-230/60/1	208-230/60/1	208-230/60/1	
Climate	Class	-	T1	T1	T1	T1	
Noise	IDU UT,T	dB	51 dB↓	41 dB↓	43 dB↓	46 dB↓	
1,0136	ODU	dB	60 dB↓	51 dB↓	53 dB↓	57 dB↓	
Net Size	IDU	mm	1055*299*215	820*299*215	820*299*215	1055*299*215	
(W*D*H)	ODU	71111	940*998*330	790*548*285	790*548*285	880*638*310	
Weight	IDU	kg	12.5	8.9	8.9	11.5	
vveigitt	ODU	Ng	68.2	32.4	32.4	38.1	
	Cooling	IDU	61 ~ 90 °F	61 ~ 90 °F	61 ~ 90 °F	61 ~ 90 °F	
Operation	Cooting	ODU	14 ~ 115 °F	-0.4 ~ 115 °F	-0.4 ~ 115 °F	-0.4 ~ 115 °F	
range	Heating	IDU	81 °F or less	81 °F or less	81 °F or less	81 °F or less	
	Heating	ODU	-5.1 ~ 75 °F	-13 ~ 75 °F	-13 ~ 75 °F	-13 ~ 75 °F	

	Model		AR18CSFCMWKNCV	AR24CSFCMWKNCV	AR09CSDACWKNCV	AR12CSDACWKNCV	
Rating	Mode	Unit	Wall-mounted	Wall-mounted	Wall-mounted	Wall-mounted	
	T1 Cool	Btu/h	18000	22000	9000	12000	
Capacity T3 Cool Heat		Btu/h	-	-	-	-	
		Btu/h	21000	24000	11000	12000	
	T1 Cool	W	1635	2100	580	890	
Power Input	T3 Cool	W	-	-	-	-	
	Heat	W	1850	2290	730	830	
	T1 Cool	А	7.4	9.8	2.8	4.2	
Current	T3 Cool	А	-	-	-	-	
	Heat	-	8.2	10.5	3.4	3.8	
	EER	Btu/hW	11	10.50	15.50	13.50	
Efficiency	-		=	-	-	-	
	COP	W/W	11.35	10.50	15.05	14.45	
Dehumio	difying	l/hr.	2.5	2.5	2.5	2.5	
	IDU	-	QF3	QF3	QF2	QF2	
Platform	ODU	-	Q-480	P-520	N-SI	N-SI	
_	Main	-	Φ7, 2R*10S*825.5mm, H1.3, N.G.S, 4by4	Φ7, 2R*10S*825.5mm, H1.3, Hydrophilic, 4by4	Φ7, ( 2R*10S+1R*4S )*660mm, (H1.3+H1.3), N.G.S, 1by2	Φ7, ( 2R*10S+1R*4S )*660mm, (H1.3+H1.3), N.G.S, 1by2	
Evap	Sub	-	Φ7, 2R*5(6)S*826mm, H1.3, N.G.S : (S3-3)	Φ7, 2R*5(6)S*825.5mm, H1.3, Hydrophilic : (S3-4)	Φ7, ( 2R*6S+1R*4S )*660mm, (H1.3+H1.3), N.G.S : (S2-3)	Φ7, ( 2R*6S+1R*4S )*660mm, (H1.3+H1.3), N.G.S : (S2-3)	
Cond	Main	-	Φ7W, 2R*28S*906.8mm, Corrugate1.5, N.G.S, 4by4by1	Φ7W, 2R*36S*906.8mm, Corrugate1.5, N.G.S, 5by5by1	Φ7W, 2R*24S*850/825mm, Corrugate1.5, N.G.S, 4by4by2	Φ7W, 2R*24S*850/825mm, Corrugate1.5, N.G.S, 4by4by2	
	Sub	-	-	-	-	-	
6	Model	-	UG9TK3150FE4	UG8TH8265FEW	KTN130D42UFR	KTN130D42UFR	
Comp	OLP	-	=	-	-	-	
Matarla	Code	-	DB31-00636A	DB31-00636A	DB31-00636A	DB31-00636A	
Motor In	Name	-	-	-	-	-	
Matas Out	Code	-	DB31-00642C DB31-00579A DB31-0		DB31-00642C	DB31-00642C	
Motor Out	Name	-	=	-	-	-	
Expansion	Φ*L	-	Ф1.65	Ф1.65	Ф1.4	Ф1.4	
Defeirement	type	-	R410A	R410A	R410A	R410A	
Refrigerant	charge	g	1300 g	1800 g	1150 g	1150 g	
SVC Valve	Liquid / Gas	-	Ф6.35/Ф12.7	Ф6.35/Ф15.88	Ф6.35/Ф9.52	Ф6.35/Ф9.52	
Tube	Dis. / Suc.	-	Ф9.52/Ф12.7	Ф9.52/Ф15.88	Ф9.52/Ф12.7	Ф9.52/Ф12.7	
Drain hose	D*L	mm	20*550	20*550	20*550	20*550	
4-WAY	V/V	-	-	-	-	-	
Power S	upply	V/Hz/Φ	208-230/60/1	208-230/60/1	208-230/60/1	208-230/60/1	
Climate	Class	-	T1	T1	T1	T1	
Noise	IDU UT,T	dB	48 dB↓	51 dB↓	41 dB↓	43 dB↓	
	ODU	dB	57 dB↓	60 dB↓	51 dB↓	53 dB↓	
Net Size	IDU	mm	1055*299*215	1055*299*215	889*299*215	889*299*215	
(W*D*H)	ODU		880*638*310	880*798*310	790*548*285	790*548*285	
Weight	IDU	kg	11.5	11.5	10.1	10.1	
	ODU	9	38.1	55.6	32.4	32.4	
	Cooling	IDU	61 ~ 90 °F	61 ~ 90 °F	61 ~ 90 °F	61 ~ 90 °F	
Operation	Cooting	ODU	-0.4 ~ 115 °F	-0.4 ~ 115 °F	-0.4 ~ 115 °F	-0.4 ~ 115 °F	
range	Heating	IDU	81 °F or less	81 °F or less	81 °F or less	81 °F or less	
	cating	ODU	-13 ~ 75 °F	-13 ~ 75 °F	-13 ~ 75 °F	-13 ~ 75 °F	

	Model		AR15CSDACWKNCV	AR18CSDACWKNCV	AR24CSDACWKNCV	AR24CSDADWKNCV
Rating	Mode	Unit	Wall-mounted	Wall-mounted	Wall-mounted	Wall-mounted
	T1 Cool	Btu/h	15000	18000	21000	21000
Capacity	T3 Cool	Btu/h	-	-	-	-
	Heat	Btu/h	15000	20000	25000	24500
	T1 Cool	W	1070	1385	1680	1680
Power Input T3 Cool		W	-	-	-	-
	Heat	W	980	1570	2000	1950
	T1 Cool	А	5	6.2	7.6	7.6
Current	T3 Cool	A	-	-	-	-
	Heat	-	4.5	7	9	9
	EER	Btu/hW	14.00	13.00	12.50	12.50
Efficiency	_		-	-	-	-
2	COP	W/W	15.30	12.75	12.50	12.55
Dehumic		l/hr.	2.5	2.5	2.5	2.5
Denami	IDU	-	QF3	QF3	QF3	QF3
Platform	ODU	_	P-520	P-520	UB1	UB1
	Main	-	Φ7, ( 2R*10S+1R*4S )*825.5mm, (H1.3+H1.3), Hydrophilic, 4bv4	Φ7, ( 2R*10S+1R*4S )*825.5mm, (H1.3+H1.3), Hydrophilic, 4by4	Φ7, ( 2R*10S+1R*4S )*825.5mm, (H1.3+H1.3), Hydrophilic, 4by4	Φ7, ( 2R*10S+1R*4S )*825.5mm, (H1.3+H1.3), Hydrophilic, 4by4
Evap	Sub	-	Φ7, ( 2R*6S+1R*4S )*825.5mm, (H1.3+H1.3), Hydrophilic : (S3-6)	Φ7, ( 2R*6S+1R*4S )*825.5mm, (H1.3+H1.3), Hydrophilic : (S3-6)	Φ7, ( 2R*6S+1R*4S )*825.5mm, (H1.3+H1.3), Hydrophilic : (S3-7)	Φ7, ( 2R*6S+1R*4S )*825.5mm, (H1.3+H1.3), Hydrophilic: (S3-7)
Cond	Main	-	Φ7W, 2R*36S*906.8mm, Corrugate1.5, N.G.S, 5by5by1	Φ7W, 2R*36S*906.8mm, Corrugate1.5, N.G.S, 5by5by1	Φ7W, 2R*46S*950mm, Corrugate1.5, N.G.S, 8by8	Φ7W, 2R*46S*950mm, Corrugate1.5, N.G.S, 8by8
	Sub	-	-	-	-	-
	Model	-	KTN150D42UFR	UG8TH8265FEW	UG8TH8265FJW	UG8TH8265FJW
Comp	OLP	-	-	-	-	-
	Code	-	DB31-00637A	DB31-00637A	DB31-00637A	DB31-00637A
Motor In	Name	-	-	-	-	-
	Code	-	DB31-00579A	DB31-00579A	DB31-00579A	DB31-00579A
Motor Out	Name	-	-	-	-	-
Expansion	Φ * L	-	Φ1.65	Φ1.65	Ф1.65	Ф1.65
· ·	type	_	R410A	R410A	R410A	R410A
Refrigerant	charge	g	1600 g	1800 g	2500 g	2500 g
SVC Valve	Liquid / Gas	-	Ф6.35/Ф12.7	Ф6.35/Ф12.7	Ф6.35/Ф15.88	Ф6.35/Ф15.88
Tube	Dis. / Suc.	-	Ф9.52/Ф12.7	Ф9.52/Ф15.88	Ф9.52/Ф15.88	Ф9.52/Ф15.88
Drain hose	D*L	mm	20*550	20*550	20*550	20*550
4-WAY	′ V/V	-	-	-	-	-
Power S	upply	V/Hz/Φ	208-230/60/1	208-230/60/1	208-230/60/1	208-230/60/1
Climate	Class	-	T1	T1	T1	T1
	IDU UT,T	dB	46 dB↓	48 dB↓	51 dB↓	51 dB↓
Noise	ODU	dB	57 dB↓	57 dB↓	60 dB↓	60 dB↓
Net Size	IDU		1055*299*215	1055*299*215	1055*299*215	1055*345*215
(W*D*H)	ODU	mm	880*798*310	880*798*310	940*998*330	880*798*310
	IDU		11.5	11.5	12.5	13.3
Weight	ODU	kg	49.0	55.6	68.2	55.6
		IDU	61 ~ 90 °F	61 ~ 90 °F	61 ~ 90 °F	61 ~ 90 °F
Operation	Cooling	ODU	-0.4 ~ 115 °F	-0.4 ~ 115 °F	-0.4 ~ 115 °F	-0.4 ~ 115 °F
range		IDU	81 °F or less	81 °F or less	81 °F or less	81 °F or less
range	Heating	ODU	-13 ~ 75 °F	-13 ~ 75 °F	-13 ~ 75 °F	-13 ~ 75 °F

### 2-3 The comparative specification of product

Model		DEVELOPMENT MODEL				
		AR09CSDABWKNCV	AR12CSDABWKNCV	AR15CSDABWKNCV	AR18CSDABWKNCV	
	Indoor Unit					
Design	Outdoor Unit	SAMSUNG	SAMSUNG	SAMSUNG	SAMSUNG	
Not Woight	Indoor Unit	10.1	10.1	11.5	11.5	
Net Weight	Outdoor Unit	32.4	32.4	49.0	55.6	
Not Discosion	Indoor Unit	889*299*215	889*299*215	1055*299*215	1055*299*215	
Net Dimension	Outdoor Unit	790*548*285	790*548*285	880*798*310	880*798*310	
Naine	Indoor Unit	41 dB↓	43 dB↓	46 dB↓	48 dB↓	
Noise	Outdoor Unit	51 dB↓	53 dB↓	57 dB↓	57 dB↓	
Air Purifyin	g System	EASY CLEAN FILTER	EASY CLEAN FILTER	EASY CLEAN FILTER	EASY CLEAN FILTER	
Indoor D	isplay	88 SEG	88 SEG	88 SEG	88 SEG	

Model		DEVELOPMENT MODEL				
		AR24CSDABWKNCV	AR09CSFCMWKNCV	AR12CSFCMWKNCV	AR15CSFCMWKNCV	
	Indoor Unit					
Design	Outdoor Unit	SAMSUNG	SAMSUNG	SAMSUNG	SAMSUNG	
Not Woight	Indoor Unit	12.5	8.9	8.9	11.5	
Net Weight	Outdoor Unit	68.2	32.4	32.4	38.1	
Nat Diagramia	Indoor Unit	1055*299*215	820*299*215	820*299*215	1055*299*215	
Net Dimension	Outdoor Unit	940*998*330	790*548*285	790*548*285	880*638*310	
Noise	Indoor Unit	51 dB↓	41 dB↓	43 dB↓	46 dB↓	
	Outdoor Unit	60 dB↓	51 dB↓	53 dB↓	57 dB↓	
Air Purifyin	g System	EASY CLEAN FILTER	EASY CLEAN FILTER	EASY CLEAN FILTER	EASY CLEAN FILTER	
Indoor D	Pisplay	88 SEG	88 SEG	88 SEG	88 SEG	

### 2-3 The comparative specification of product

Model		DEVELOPMENT MODEL				
		AR18CSFCMWKNCV	AR24CSFCMWKNCV	AR09CSDACWKNCV	AR12CSDACWKNCV	
	Indoor Unit					
Design	Outdoor Unit	SAMSUNG	SAMSUNG	SAMSUNG	SAMSUNG	
NIa+ Waish+	Indoor Unit	11.5	11.5	10.1	10.1	
Net Weight	Outdoor Unit	38.1	55.6	32.4	32.4	
Not B'	Indoor Unit	1055*299*215	1055*299*215	889*299*215	889*299*215	
Net Dimension	Outdoor Unit	880*638*310	880*798*310	790*548*285	790*548*285	
Noise	Indoor Unit	48 dB↓	51 dB↓	41 dB↓	43 dB↓	
Noise	Outdoor Unit	57 dB↓	60 dB↓	51 dB↓	53 dB↓	
Air Purifyin	g System	EASY CLEAN FILTER	EASY CLEAN FILTER	EASY CLEAN FILTER	EASY CLEAN FILTER	
Indoor D	isplay	88 SEG	88 SEG	88 SEG	88 SEG	

Model		DEVELOPMENT MODEL				
		AR15CSDACWKNCV	AR18CSDACWKNCV	AR24CSDACWKNCV	AR24CSDADWKNCV	
	Indoor Unit					
Design	Outdoor Unit	SAMSUNG	SAMSUNG	SAMSUNG	SAMSUNG	
Not Woight	Indoor Unit	11.5	11.5	12.5	13.3	
Net Weight	Outdoor Unit	49.0	55.6	68.2	55.6	
Net Discossion	Indoor Unit	1055*299*215	1055*299*215	1055*299*215	1055*299*215	
Net Dimension	Outdoor Unit	880*798*310	880*798*310	940*998*330	940*998*330	
Noise	Indoor Unit	46 dB↓	48 dB↓	51 dB↓	51 dB↓	
	Outdoor Unit	57 dB↓	57 dB↓	60 dB↓	60 dB↓	
Air Purifyin	g System	EASY CLEAN FILTER	EASY CLEAN FILTER	EASY CLEAN FILTER	EASY CLEAN FILTER	
Indoor D	isplay	88 SEG	88 SEG	88 SEG	88 SEG	

### 2-4 Accessory and Option Specifications

Item	Descriptions	Code No.	Q'ty	Remark
	ACCYLLANGER	DB90-11453A (Q1, Q2)	1	
	ASSY HANGER	DB90-11454A (Q3)	1	
080	ASSY WIRELESS REMOCON	DB96-25318V	1	Indoor unit case
	MANUAL USER	DB68-12013A	1	
	MANUAL INSTALL	DB68-12003A	1	
	Batteries for Remote controller	4301-000121	2	
	Rubber Leg	DB67-01533A	4	Outdoor unit
	Drain plug		1	case

### 3. Alignment and Adjustments

#### 3-1 Test Mode

#### ◆ How to Approach Test Mode

You can approach the test mode by pressing the on/off switch of indoor unit for 5 seconds.



#### ◆ Test mode operation option

After installing the air conditioner, check whether each subordinate is normally operated or not by operating the test mode.

- When an Error occurs, display the Error Mode.
- Operation Mode: Cool mode. operate the cool mode by operating the compressor by force without the compressor ON/OFF according to the set temperature/indoor temperature. (Do not follow the antifreeze control)
- Up-down louver: Up-down swing mode
- Indoor Fan : Turbo



• Because the heat mode operate the cool mode by force not related to the set temperature / indoor temperature, check whether each subordinate is operated normally or not after completing installation and must turn off the power of the air conditioner.

### 3-2 Display Error and Check Method

### 3-2-1 Indoor Display Error and Check Mathod

ERROR MODE	TYPE	
7-SEG	INDOOR/ OUTDOOR	DESCRIPTION
C101, C102		Communication error
C108		Set address error
C121		Room TH sensor error
C122, C123		INDOOR MID, INDOOR IN EVA-TH sensor error
C140		Dust sensor error
C142	INDOOR	Humidity error
C143	INDOOR	Motion sensor error
C154		Fan error(indoor)
C161		Mixed operation error
C163		Option error
C187		K1 filter feed back error
C665		Drain pump error

#### \*Note\*

If the set doesn't work (No power), check the thermal fuse of terminal block OPEN or SHORT with Multimeter.

<sup>\*</sup> Measure the thermal fuse housing PIN#1~2 : OPEN(disconnection)-> defective product

### 3-2 Display Error and Check Method

### 3-2-2 Outdoor Display Error and Check Mathod

	ERROR	MODE	DESCRIPTION	
7-SEG	YEL	GRN	RED	DESCRIPTION
-	0	0	0	Power off /VDD NG
-	•	•	•	Power on reset (1sec)
-	0	•	•	Normal operation
-	0	0	•	Abnormal communication
-	0	•	•	(Indoor <-> Outdoor)
C464	0	0	•	IPM over current (O.C) error
C461	0	•	0	Comp. strating error
C470	0	•	0	EEPROM data error (no data)
C466	-	-		DC-Link voltage under / Over error
C484		•		PFC over load error
C483				Over voltage protection error
C221	•	0	•	OUT-TH (Outdoor temperature) sensor error
C416	•	0	•	DIS-TH (Discharge temperature) Over error
C251	•	•	0	DIS-TH (Discharge temperature) sensor error
C468				Current sensor error
C474			•	Heatsink sensor error
C485				Input current sensor error
C465			0	Comp. V_limit/ I_limit error
C500				Heatsinkover temperature error
C231		•		CON-TH (Cond temperature) sensor error
C203	•	•	•	Time out Comp. (Inv Micom <->Main Micom)
C458	•	0	0	Fan error
C471	•	0	•	EEPROM data error (Main Micom <-> INV Micom)
C467	•	0	•	Comp. wire missing error
C440				Prohibit operation condition error (Heating)
C441				Prohibit operation condition error (Cooling)
C469		•		DC-Link voltage sensor
C488				AC Input voltage sensor
C462	•		•	AC Input I_limit trip error
C554			0	Gas leak error
C574				Gas shortage error
C422	•	•	0	EEV or valve close error-self diagnosis
-	0	•	•	Test operation at Cooling mode
-	•	•	•	Test operation at Heating mode

:LAMP ON

O: LAMP OFF

: LAMP BLINK

### 3-3 Setting Option Setup Method

#### Ex) Option No.:


#### Enter the Option Setup mode.


- 1. Tack out the batteries of remote control.
- 2. Press the temperature  $\begin{bmatrix} + \\ r_{\text{temp}} \end{bmatrix}$  button simultaneously and insert the battery again.
- 3. Make sure the remote control display shown as





#### Step 2

Enter the Options Setup mode and select your options asscording to the following procedure.









### Option code:

Madal	Option code	
Model	General	Install
AR07CSDAFWKNCV	011A35-17C0E7-271416-371449	024012-100150-200301-300346
AR09CSDABWKNCV	011A35-17C0F7-271A20-371449	024012-100150-200301-300346
AR12CSDABWKNCV	011A35-17C217-272323-371449	024012-100150-200301-300346
AR15CSDAFWKNCV	011A35-17C227-272C38-371449	024012-100150-200301-300346
AR15CSDABWKNCV	011A35-16C23B-272C30-371449	024012-100150-200301-300357
AR18CSDABWKNCV	011A35-16C23B-27353B-371449	024012-100150-200301-300357
AR24CSDABWKNCV	011A35-15C29D-273E49-371649	024012-100150-200301-300357
AR07CSFCMWKNCV	011A35-17C0DA-271416-372849	024010-100150-200301-300335
AR09CSFCMWKNCV	011A35-17C0EA-271A20-372849	024010-100150-200301-300335
AR12CSFCMWKNCV	011A35-17C0FA-272323-372849	024010-100150-200301-300335
AR15CSFCMWKNCV	011A35-15C21B-272C2C-372449	024010-100150-200301-300357
AR18CSFCMWKNCV	011A35-15C21B-27353E-372449	024010-100150-200301-300357
AR24CSFCMWKNCV	011A35-15C24B-274046-371449	024010-100150-200301-300357
AR24CSDADWKNCV	011A35-15C29D-273E48-371649	024012-100150-200301-300357

# 4. Disassembly and Reassembly

### ♦ Necessary Tools

Item	Remark
+SCREW DRIVER Q'ty1 ea. To assembly and disassembly the screw	
MONKEY SPANNER Q'ty1 ea. To assembly and disassembly the Fan motor and Compressor	
- SCREW DRIVER Q'ty1 ea. To assembly and disassembly the screw	CONTROL CONTRO

### 4-1. Indoor Unit

NO.	Parts	Procedure	Remark
1	PANEL-FRONT	1) Stop the driving of air conditioner and shut off main power supply.	
		2) Detach FILTER PRE from the PANEL FRONT.	
		3) The COVER PANEL is fixed to body by hooks in center and side area.	
		4) Separate the hook pulling end of the COVER PANEL as shown in figures.(Watch out for the damage of hooks)	

PANEL-FRONT	Assembly of Cover Panel after service end Piping and Drain Hose must be caseful not to damage and progress must be done with both hands Need to check all bottom hooks in holes of the main frame before you push to assemble.	
	▲ Caution: - Assemble(push) side hooks - Assemble(push) center 5 hooks each.	
	PANEL-FRUNI	Assembly of Cover Panel after service end.  - Piping and Drain Hose must be caseful not to damage and progress must be done with both hands.  - Need to check all bottom hooks in holes of the main frame before you push to assemble.  Acaution:  - Assemble(push) side hooks  - Assemble(push) center 5 hooks

NO.	Parts	Procedure	Remark
1	PANEL-FRONT	5) The GRILLE INLET is fixed to body by hooks in the center and side area.	
		6) Separate the hook pulling end of the GRILLE INLET as shown in figures.(Watch out for the damage of hooks)	
		7) To detach the PANEL FRONT from the main frame, unfasten 2 screws at the bottom. (use (+) Screw Driver)	
		8) To detach the PANEL FRONT from the main frame, loosen 4 hook structures. When separate the hooks: pull out each ribs near the hooks as shown in figures. (Watch out for	
		the damage of hooks)	

NO.	Parts	Procedure	Remark
1	PANEL-FRONT	9)Raise the PANEL FRONT upward as shown in the figure to separate the 3 hooks.	
2	CONTROL-IN	10)To open the CONTROL-IN, raise the side flanges of the PLATE-RIGHT at an angle and unlock 2 hooks.	
		11)To detach the CONTROLIN, unfasten a screw back of the PLATE-LEFT as shown in figures. (use (+) Screw Driver)	

NO.	Parts	Procedure	Remark
2	CONTROL-IN	12)Separate Fan Moter wire as shown in figures.  • Caution: When you separate the connector, pull pressing the locking button.	
		13)Separate Blade Moter wire as shown in figures.  • Caution: When you separate the connector, pull pressing the locking button.	
		14)Cut off the Cable Tie tied up wires.	

NO.	Parts	Procedure	Remark
2	CONTORL IN	15)Unfasten a screw of the Ground wire and pick up Temperature wires from ASSY EVAP. (Use (+) Screw Driver.)	
		16) The CONTROL-IN is fixed to HOLER PIPE by a hook bottom of the case as shown in the last figure. (Please loosen remaining connectors before detaching CASECONTROL.  A Caution: When you separate the connector, pull pressing the locking button	
		17) Put down of the HOLDER PIPE and push up the hook and lean side the case as shown in figures.	

NO.	Parts	Procedure	Remark
3	Parts TRAY DRAIN	18) To detach the TRAY DRAIN from the main frame, pull the bottom of the TRAY DRAIN and it leans toward to you as shown in figures.	
		19) Pull out the Drain Hose.	MI P B

NO.	Parts	Procedure	Remark
4	EVAPORATOR	20) The HOLDER PIPE is fixed to body by 2 hooks as shown in the figure.	
		21) To detach the HOLDER PIPE from the main frame,loosen 2 hook structhres. When separate hooks: Use the (-) Screw Driver. Insert the (-) Screw Driver into the gap of the hook and lean to the Moter side as shown in figures. (Watch out for the damate of hooks)	
		22)Remove the HOLDER PIPE.	
		23)Unfasten a screw of the Fan Moter side. (Use (+) Screw Driver.)	
		24)Unfasten 2 screws of the opposite side of the Fan Moter. (Use (+) Screw Driver.)	

NO.	Parts	Procedure	Remark
4	EVAPORATOR	25) Pull up the EVAPORATOR of the opposite side of the Fan Moter	
		26) loosen a hook of the Fan Moter side.	
		27) Pull up the EVAPORATOR toward to you.	

NO.	Parts	Procedure	Remark
5	FAN MOTOR & CROSS FAN	28) Unfasten a screw on the COVER MOTER. (Use (+) Screw Driver.)	
		29) Unwind the Moter Wire.	
		30)Detach the COVER MOTER.	
		31) Unfasten a screw of the CROSS FAN a little. (Use (+) Screw Driver.)	
		32)Raise up the CROSS FAN of the left side and pull out from the Moter.	

# **4-2. Outdoor Unit (N-SI)** \*\*09/12\*\*\*\*\*\*

NO.	Parts	Procedure	Remark
1	Common work	1) Loosen each screws and detach the cabi Top cover.	SAMSUNG
		2) Loosen screws of the cabi front and detach it.	
			SAM

NO.	Parts	Procedure	Remark
		3) Remove the 4 Cond Bar from the holder of outdoor unit cabinet.  * This process is supported by heating models only	
		4) Loosen ing screws from the Cabi Front Lh and detach it.	
		5) Loosen ng screws from the Cabi Side Rh and detach it.	
			HISTORY OF THE PARTY OF THE PAR

NO.	Parts	Procedure	Remark
2	Fan & Motor	1) Detach the Nut Flange like the picture on the right side. (Turn clockwise because the screw is left-handed.) (Use Monkey Spanner.)	
		2) Detach the Fan Propeller. 3) Loosen 4 fixing screws to detach the Motor. (Use Monkey Spanner.)	
		4) Disconnect the wire between Ass'y Control Out and Motor.	
		5) Loosen fixing bolts and detach the Bracket Motor	

NO.	Parts	Procedure	Remark
3	Assy Control Out	1) To remove the Cover control box : Pull the motor wire is allow sufficientspace as shown on the right side and then remove the screw.	
		2) Detach several connectors from the Assy Control Out. 3) Detach several connectors from the PCB of Assy Control Out.	
		<ol> <li>Release the refrigerant at first.</li> <li>Loosen ng screw on both sides.</li> <li>Disassemble the pipes in both inlet and outlet with welding torch.</li> <li>Detach the Heat Exchanger.</li> </ol>	

NO.	Parts	Procedure	Remark
5	Compressor	1) Loosen the ng nut and detach the Compressor Lead Wire. (Use Monkey Spanner.)	The state of the s
		2) Loosen the bolts at the bottom of Compressor like the picture on the right side. (Use Monkey Spanner.)	

# **4-3. Outdoor Unit (Q-480)** \*\*15/18\*\*\*\*\*\*\*

\*\*24CSFC\*\*\*\*

NO.	Parts	Procedure	Remark
1	COMMON WORK	1) Loosen fixing screws from the cabi side Rh and detach it.	
		2) L oosen each sc rews and detach the Cabi Top Cover.	
		3) Loosen fixing screws from the cabi side.	
		4) Loosen fixing screws from the cabi side Rh and detach it.	

NO.	Parts	Procedure	Remark
1	COMMON WORK	5) Loosen fixing screws from the cabi front and detach it.	
			SAMSUNG
		6) L oosen fixing screws from the Cabi left and detach it and Remove the 4 Cond Bar from the holderof outdoor unit cabinet.	

NO.	Parts	Procedure	Remark
2	Fan & Motor	1) Detach the Nut Flange like the picture on the right side. (Turn clockwise because the screw is left-handed.) (Use Monkey Spanner.)	AND THE PARTY OF T
		2) Detach the Fan Propeller. 3) Loosen 4 fixing screws to detach the Motor. (Use Monkey Spanner.)	
		4) Disconnect the wire between Assy Control Out and Motor.	
		5) Loosen fixing bolts and detach the Bracket Motor	

NO.	Parts	Procedure	Remark
3	Assy Control Out	1) To remove the Cover control box : Pull the motor wire is allow sufficient space as shown on the right side and then remove the screw.	
		<ul><li>2) Detach several connectors from the Assy Control Out.</li><li>3) Detach several connectors from the PCB of Assy Control Out.</li></ul>	
4	Heat Exchanger	1) Release the refrigerant at first. 2) Loosen ng screw on both sides. 3) Disassemble the pipes in both inlet and outlet with welding torch. 4) Detach the Heat Exchanger.	

NO.	Parts	Procedure	Remark
5	Compressor	1) Loosen the ng nut and detach the Compressor Lead Wire. (Use Monkey Spanner.)	
		2) Loosen the bolts at the bottom of Compressor like the picture on the right side. (Use Monkey Spanner.)	

# **4-4. Outdoor Unit (P)** \*\*24CSDA\*\*\*\*

NO.	Parts	Procedure	Remark
1	Common Work	1) Loosen 8 fixing screw on each side of the Cabinet-Top.(Use +Screw Driver)	SAMSUNG
2	Assy cover control	1) Unscrew and remove a screw of Cover-Control. (Use + Screw Driver)	
3	Outdoor and indoor unit's power cable and communication cable	▲ Caution: Make sure shutting the power off supply before disassembling.  1) Unscrew 2 fix screws under cable holders and remove. 2) Get rid of cable tie of communication cable. 3) Unscrew the numbers of screws on terminal block and separate power and communication 'Ring' cables from terminal block. 4) Unscrew earth-wire screws and separate it.	A MANUAL PARTY AND A MANUAL PART

NO.	Parts	Procedure	Remark
4	ASSY CABINET SIDE RH	1) Unscrew and remove 11 screws on Cabinet-side RH. (Use + Screw Driver)	0.00 S
5	ASSY CABINET FRONT	1) Unscrew and remove 7 screws on Assy Cabinet Front. (Use + Screw Driver)	SAMSUNG
6	ASSY CONTROL OUT	1) Disconnect and Separate 5 Connectors of wire from Assy Control Out. 2) Separate Comp wire from each object.  • Caution: (When you disconnect BLDC motor connector you have to cut the power off first and disconnect 30 seconds later And Make sure that is impossible to connect and disconnect BLDC motor connector when the power is on)  3) Unscrew and remove 2 screws on of Assy Control out.	

NO.	Parts	Procedure	Remark
7	Fan propeller + Motor	1) Take Fan Propeller apart. 2) Unscrew and remove 4 screws on Motor to take apart Motor. (Use + Screw Driver)	
8	ASSY BRACKET MOTOR	1) Unscrew and remove 2 screws on to take apart Bracket Motor. (Use + Screw Driver)	
9	Heat Exchanger	1) Purge the Refrigerant first. 2) Unscrew the fix screw. 3) Separate the pipe from the Entrance and Exist by using a welder. 4) Separate Heat Exchanger from Unit.  A Caution: When removing the Compressor, Heat Exchanger, and Pipe, Purge the Refrigerant inside the Compressor completely and remove the pipe with a welding flame.	

### 4-5. Outdoor Unit (UB)

AR24CSDABWKXCV AR24CSDACWKXCV AR18CSDADWKXCV AR18CSDAEWKXCV AR24CSDAEWKXCV

No.	Parts	Procedure	Remark
1	Cabinet Front RH	!CAUTION : Turn o the power before disassembly necessarily.  1) Remove the 2 screws from the Cabinet Front RH and separate it. (Use +Screw Driver)	SAMSUNG  CHERCOLOR  DIGITAL INVERTER  TEXASON OF THE PROPERTY
2	Cabinet Upper	1) Remove the 9 screws which is fixed to each side of Cabinet Upper and separate it. (Use +Screw Driver)	SAMSUNG
3	Cabinet- Installation Front Part	Remove the 1 screw which is fixed to Cabinet-Installation Front Part and separate it. (Use +Screw Driver)	

No.	Parts	Procedure	Remark
4	Outdoor Unit Guard	<ol> <li>Pull out the sensor from the Outdoor Unit Guard and separate it.</li> <li>Remove the 4 screws which is fixed to Outdoor Unit Guard and separate it.(Use + Screw Driver)</li> </ol>	
5	Cabinet Rear RH	1) Pull out the sensor from the Cabinet Rear RH and separate it.  2) Remove the 4 screws which is fixed to each side of Cabinet Rear RH and separate it. (Use + Screw Driver)	
6	Cabinet- Installation Rear Part	Remove the 1 screw from the Cabinet- Installation Rear Part and separate it.(Use + Screw Driver)	

No.	Parts	Procedure	Remark
7	Cabinet Front LF	1) Unscrew and remove 8screws on Cabinet-Front LF. (Use +Screw Driver)	
8	Fan	1) Remove the one fixing nut like the picture on the right side. (Use Hexagon Wrench, Monkey Spanner, Hexagon Socket)	
9	Motor	1) Separate the Fan Propeller. 2) Remove the 4 screws which is fixed to Motor. (Use +Screw Driver) 3) Separate the Motor Wire connector from the Outdoor Unit Control Part	


No.	Parts	Procedure	Remark
10	Bracket Motor	1) Remove the 2 screws from the Bracket Motor and separate it. (Use +Screw Driver)	
11	Control Out	1) Disconnect 6 Connecters From Ass'y Control Out. 2) Unscrew and remove 4 mounting screw on Control Out. (Use +Screw Driver) 3) Separate Ass'y Control Out.	
12	4 Way Valve	1) First, discharge the refrigerant. 2) Remove the 2 screws which is fixed to Service Valve and separate it. (Use +Screw Driver) 3) Separate the inlet and outlet pipes by welding torch.  !CAUTION: If you separate the Compressor, Heat Exchanger or Pipe, please fully discharge refrigerant in the Compressor and then separate the Pipe by welding torch.	

No.	Parts	Procedure	Remark
13	EEV Valve	1) Remove the 2 screws which is fixed to Service Valve and separate it.  +Screw Driver)  (Use	
		2)Separate the inlet and outlet pipes by welding torch.	
14	Compressor	1) Remove the 1 fixing nut from the end of Cover and separate it. (Use Hexagon Wrench, Monkey Spanner, Hexagon Socket)	
		2) Separate the Felt Compressor. 3) Remove the 3 bolts from the bottom of Compressor like the picture on the right side. (Use Hexagon Wrench, Monkey Spanner, Hexagon Socket)	
15	Condenser Connection Part	1) Remove the 3 screws which is fixed to each side of Condenser Connection Part and separate it. (Use + Screw Driver)	A. Strong Stranger 10 Para

# **5. ASSY CONTROL**

# 5-1 ASSY KIT INDOOR CODE DB92-05191G, J


Model	KIT OUT
AR**CSDABWKNCV	DB92-05191J
AR**CSFCMWKNCV	DB92-05191G



No	NAME	CODE	G	J	unit
1	PLATE CONTROL-SUB	DB61-07427A	1	1	EA
2	PLATE CONTROL-LOW	DB61-07428A	1	1	EA
3	PLATE CONTROL-UP	DB61-07429A	1	1	EA
4	PLATE CONTROL-LF	DB61-07431A	1	1	EA
5	CASE CONTROL-IN	DB61-07432A	1	1	EA
6	HOLDER-WIRE	DB61-05871A	1	1	EA
7	SCREW-TAPPING	6002-001163	1	1	EA
8	SCREW-TAPPING	6002-000213	2	2	EA
9	SCREW-SPECIAL	6003-001768	2	2	EA
10	CABLE TIE	6501-001075	1	1	EA
11	W-LAN MODULE (External)	4709-003104	0	1	EA
12	SENSOR PHOTO (MDS)	DB32-00270A	0	1	EA
13	CASE PCB (External Wifi)	DB61-07464A	0	1	EA
14	COVER PCB (External Wifi)	DB63-04265A	0	1	EA
15	TERMINAL BLOCK	DB37-00033B	1	1	EA
16	ASSY PCB DISPLAY	DB92-05040C	0	1	EA
16	ASSY PCB DISPLAY	DB92-05040N	1	0	EA
18	SENSOR HUMIDITY	DB32-00272A	1	1	EA
19	ASSY CONNECTOR WIRE-POWER	DB93-17169A	1	1	EA
20	ASSY CONNECTOR WIRE-COMM	DB93-17055B	1	1	EA
21	ASSY CONNECTOR WIRE-EARTH (EVA)	DB93-14245D	1	1	EA
22	ASSY CONNECTOR WIRE-DC SIGNAL (MDS)	DB93-17170A	0	1	EA
23	ASSY CONNECTOR WIRE (EX WIFI)	DB93-17190A	0	1	EA
24	ASSY PCB MAIN-IN	DB92-05043J	1	1	EA
26	ASSY CONNECTOR WIRE-DC SIGNAL	DB93-17178A	1	1	EA

## 5-2 ASSY KIT INDOOR CODE DB92-05201F


Model	KIT OUT	
AR24CSDADWKNCV	DB92-05201F	





No	NAME	CODE	F	unit
1	PLATE CONTROL-SUB	DB61-07427A	1	EA
2	PLATE CONTROL-LOW	DB61-07428A	1	EA
3	PLATE CONTROL-UP	DB61-07429A	1	EA
4	PLATE CONTROL-LF	DB61-07431A	1	EA
5	CASE CONTROL-IN	DB61-07432A	1	EA
6	HOLDER-WIRE	DB61-05871A	1	EA
7	SCREW-TAPPING	6002-001163	1	EA
8	SCREW-TAPPING	6002-000213	2	EA
9	SCREW-SPECIAL	6003-001768	2	EA
10	CABLE TIE	6501-001075	1	EA
11	W-LAN MODULE (External)	4709-003104	1	EA
12	SENSOR PHOTO (MDS)	DB32-00270A	1	EA
13	CASE PCB (External Wifi)	DB61-07464A	1	EA
14	COVER PCB (External Wifi)	DB63-04265A	1	EA
15	TERMINAL BLOCK	DB37-00033B	1	EA
16	ASSY PCB DISPLAY	DB92-05040T	1	EA
18	SENSOR HUMIDITY	DB32-00272A	1	EA
19	ASSY CONNECTOR WIRE-POWER	DB93-17169A	1	EA
20	ASSY CONNECTOR WIRE-COMM	DB93-17055B	1	EA
21	ASSY CONNECTOR WIRE-EARTH (EVA)	DB93-14245D	1	EA
22	ASSY CONNECTOR WIRE-DC SIGNAL (MDS)	DB93-17170A	1	EA
23	ASSY CONNECTOR WIRE (EX WIFI)	DB93-17190A	1	EA
24	ASSY PCB MAIN-IN	DB92-05200B	1	EA
26	ASSY CONNECTOR WIRE-DC SIGNAL	DB93-17178A	1	EA

# 5-3 ASSY KIT OUTDOOR CODE DB92-05037H,J

Model	KIT OUT
AR09/12CSDABWKXCV AR09/12CSFCMWKXCV	DB92-05037H
AR09/12CSDACWKXCV	DB92-05037J








No	NAME	CODE	Н	J	Unit
1	ASSY-THERMAL GREASE	0205-000178	0.002	0.002	Kg
2	SCREW-MACHINE (TB)	6001-000722	2	2	EA
3	SCREW-TAPPING (CLAMP 4EA)	6002-000234	4	4	EA
4	SCREW-TAPPING (CLAMP 2EA, CASE 1EA)	6002-000239	3	3	EA
5	SCREW-TAPPING (PBA)	6002-000630	1	1	EA
6	SCREW-TAPPING (EARTH)	6003-001768	4	4	EA
7	ASSY-SCREW MACHINE (H/S parts)	DB91-00933A	3	3	EA
8	HOLDER-WIRE CLAMP	DB61-00250A	2	2	EA
9	CASE CONTROL LOW (WW, SI,Q-480	DB61-06722C	1	1	EA
10	COVER CONTROL OUT (WW, SI)	DB63-04234D	1	1	EA
11	PLATE CONTROL(N-SI)	DB61-05897C	1	1	EA
12	SPRING	DB81-00635A	2	2	EA
13	SEAL	DB62-11637T	0.153	0.153	mm
14	LABEL	DB98-34030A	1	1	EA
15	HEAT SINK	DB62-13008A	1	1	EA
16	TERMINAL BLOCK	DB65-00274A	1	1	EA
16	TERMINAL BLOCK	DB37-00036B	1	1	EA
17	ASSY CONNECTOR WIRE- POWER	DB93-16371A	1	1	EA
18	ASSY CONNECTOR WIRE- COMM	DB93-16402A	1	1	EA
19	ASSY CONNECTOR WIRE- COMP	DB93-09497F	1	1	EA
20	ASSY CONNECTOR WIRE- AC SIGNAL	DB93-17177A	1	1	EA
21	ASSY CONNECTOR WIRE- EARTH	DB93-12121B	1	1	EA
22	ASSY CONNECTOR WIRE- EARTH	DB93-12121B	1	1	EA
23	ASSY CONNECTOR WIRE- REACTOR	DB93-17175C	1	1	EA
30	ASSY CONNECTOR WIRE- DC SIGNAL	DB93-16704A	0	1	EA
31	ASSY CONNECTOR WIRE- HEATER TO TB	DB93-13180A	0	1	EA
32	ASSY PCB SUB-HEATER	DB93-13220A	0	1	EA
34	SENSOR TEMP	DB95-05164A	1	1	EA
35	ASSY MODULE	DB92-04837U	1	0	EA
35	ASSY MODULE	DB92-04837V	0	1	EA

# 5-4 ASSY KIT OUTDOOR CODE DB92-05037K


AR15CSFCMWKXCV AR18CSFCMWKXCV



No	NAME	CODE	Q'ty	unit
1	ASSY-THERMAL GREASE	0205-000178	0.002	KG
2	SCREW-MACHINE	6001-000722	2	EA
3	SCREW-TAPPING	6002-000234	4	EA
4	SCREW-TAPPING	6002-000239	3	EA
5	SCREW-TAPPING	6002-000630	1	EA
6	SCREW-SPECIAL	6003-001768	4	EA
7	ASSY-SCREW MACHINE	DB91-00933A	3	EA
8	HOLDER-WIRE CLAMP	DB61-00250A	2	EA
9	CASE CONTROL LOW	DB61-06722C	1	EA
10	COVER CONTROL OUT	DB63-04234D	1	EA
11	PLATE CONTROL	DB61-04690B	1	EA
12	SPRING	DB81-00635A	2	EA
13	SEAL	DB62-11637T	0.153	EA
17	LABEL	DB98-34030A	1	EA
18	HEAT SINK	DB62-13008A	1	EA
19	TERMINAL BLOCK	DB65-00274A	1	EA
20	TERMINAL BLOCK	DB37-00036B	1	EA
21	ASSY CONNECTOR WIRE- POWER	DB93-16371A	1	EA
22	ASSY CONNECTOR WIRE- COMM	DB93-16402A	1	EA
23	ASSY CONNECTOR WIRE- COMP	DB93-09497B	1	EA
24	ASSY CONNECTOR WIRE-AC SIGNAL	DB93-17177A	1	EA
25	ASSY CONNECTOR WIRE- EARTH	DB93-12121B	1	EA
26	ASSY CONNECTOR WIRE- EARTH	DB93-12121B	1	EA
27	ASSY CONNECTOR WIRE- REACTOR	DB93-17175C	1	EA
33	SENSOR TEMP	DB32-00257A	1	EA
34	ASSY MODULE	DB92-04837U	1	EA


# 6. Wiring Diagram

# 6-1 Indoor Unit (All models)




#### 6-2 Outdoor Unit

AR09CSDABWKXCV AR12CSDABWKXCV AR09CSFCMWKXCV AR12CSFCMWKXCV AR15CSFCMWKXCV AR18CSFCMWKXCV AR09CSDACWKXCV AR12CSDACWKXCV




#### 6-2 Outdoor Unit

AR15CSDABWKXCV AR18CSDABWKXCV AR24CSDABWKXCV AR24CSFCMWKXCV AR15CSDACWKXCV AR18CSDACWKXCV AR24CSDACWKXCV



# 7. PCB Diagram


## 7-1 Indoor Main PCB CODE DB92-05043J



CN810 : STEP MOTOR(V-Blade)	CN800 : STEP MOTOR(H-BLADE1)	CN801 : STEP MOTOR(H-BLADE3)	
#1: 12V	#1: 12V	#1: 12V	
#2: SIGNAL1	#2: SIGNAL1	#2: SIGNAL1	
#3: SIGNAL2	#3: SIGNAL2	#3: SIGNAL2	
#4: SIGNAL3	#4: SIGNAL3	#4: SIGNAL3	
#5: SIGNAL4	#5: SIGNAL4	#5: SIGNAL4	
CN230 : DOWNLOAD	CN430 : FJM SUB	CN100 : DISPLAY&Thermistor&Wifi	
#1: COM1_RXD	#1: COM2_RXD	#1: LED_DIO	#2: 5VDC
#2: COM1_TXD	#2: COM2_TXD	#3: LED_CLK(DIS)	#4: GND
#3: nTRST	#3: COM2_INVERSE	#5: LED_RST(DIS)	#6: H_ROOM_TEMP
#4: TDO	#4: COM2_ENABLE	#7: POWER_SW	#8: HUM_SENSOR
#5: TCK	#5: EXT_CTRL	#9:GND	#10: ROOM_TEMP
#6: TDI	#6: COMP_CHK	#11:5VDC	#12: GND
#7: TMS	#7: ERROR_CHK	#13: REMOCON_INT(DIS)	#14: EVA_IN_TEMP
#8: TraceCLK	#8: COM2_VCC_PS_OUT	#15: ADDRESS_SW(DIS)	#16: GND
#9: GND	#9: GND	#17: MAIN_RX(DIS_WIFI)	#18: EVA_OUT_TEMP
#10: 5VDC	#10: 12VDC	#19: MAIN_TX(DIS_WIFI)	#20: GND
#11: 5VDC	#11: COM2_PCTRL_MICOM	#21: WIFI_CONTROL(DIS_WIFI)	#22: NULL
#12: BOOT	#12:COM2_VCHECK_A	#23: 12VDC	#24: NULL
#13: RESET	#13:COM2_VCHECK_B	#25: MDS_2(DIS_DETECT)	#26: NULL
#14: Trace3	#14:COM2_MICOM_AD	#27: MDS_1(DIS_DETECT)	#28: 5VDC_1
#15: NULL	CNP100 : AC POWER	CN900 : BLDC MOTOR	
#16: NULL	#1:L	#1: 310VDC	
#17: GND	#2 : NULL	#2: NULL	
#18: Trace2	#3 : N	#3: AGND	
#19: Trace1	#4: NULL	#4: 15VDC	
#20: Trace0	#5 : GND	#5: MOTOR SIGNAL	
CN390 : WIFI	CN320 : 485COMM	#6: FEEDBACK SIGNAL	
#1: MAIN_RX	#1: RX		
#2: MAIN_TX	#2: TX		
#3: CONTROL			
#4: GND			
#5: 12V			

## 7-2 Outdoor Main PCB CODE DB92-04837U, V


AR09CSDABWKXCV AR12CSDABWKXCV AR09CSFCMWKXCV AR12CSFCMWKXCV AR15CSFCMWKXCV AR18CSFCMWKXCV AR09CSDACWKXCV AR12CSDACWKXCV



CNP001 : POWER(N)		CNP002 ; POWER(L)		
#1 : POWER(N)		#1 : POWER(L)		
CNP003 : EARTH		CNP301 : COMM (C)		
#1 :EARTH		#1 : COMM (C)		
CNP051,CNP052 : RE	ACTOR	CNP401 : COMP		
#1 :REACTOR SIGNA	AL.	#1:COMP SIGNAL(W)		
#2 :REACTOR SIGNA	\L	#2:COMP SIGNAL(V)		
		#3:COMP SIGNAL(U)		
CNP551 : EEPROM		CNP501 : DOWNLOAD		
#1:GND	#5:EEP_SO_MICOM_RX	#1 :RXD	#9,17:GND	
#2:NULL	#6:EEP_SI_MICOM_TX	#2:TXD	#10,11:5VDC	
#3:5VDC	#7:EEP_CLK	#3:BOOT	#12,13,15,16:NULL	
#4:EEP_CS		#4:TDO	#14:TRACE3	
		#5:TCK	#18:TRACE2	
		#6:TDI	#19:TRACE1	
		#7:TMS	#20:TRACE0	
		#8:TRACECLK		
CN251 : OLP SENSO	R	CNP571 : ECO-DOWNLOAD		
#1: OLP SENSOR		#1:5VDC	#4:GND	
#2: GND		#2:RXD_INV	#5:NULL	
		#3:TXD_INV		
CNP041 : AC FAN MOTOR		CNP031: 4WAY		
#1 :AC	#4:NULL	#1:AC SIGNAL		
#2:NULL	#5:AC	#2:NULL		
#3:MOTOR SIGNAL		#3:AC SIGNAL		


### 7-3 Outdoor PCB Inverter CODE DB92-04838Q, R

AR15CSDABWKXCV AR18CSDABWKXCV AR24CSDABWKXCV AR24CSFCMWKXCV AR15CSDACWKXCV AR18CSDACWKXCV AR24CSDACWKXCV



CNP001 : POWER_L	CN551: INV_DOWNLOAD	CN320 : SUB COMM
#1: L	#1: RXD_INV	#1: 5VDC
CNP002 : POWER_N	#2: TXD_INV	#2: ENABLE
#1: N	#3: BOOT	#3: INVERSE
CNP003 : POWER_GND	#4: TDO_INV	#4: TXD
#1: GND	#5: TCK_INV	#5: RXD
CNP004 : COMM_GND	#6: TDI_INV	#6: GND
#1: GND	#7: TMS_INV	#7: 12VDC
CNP051/052 : REACTOR	#8: nTRST_INV	CN210 : MAIN_DOWNLOAD
#1: REACTOR#1	#9: GND	#1: RXD_MAIN
#1: REACTOR#2	#10: 5VDC	#2: TXD_MAIN
CNP402 : COMP	#11: 5VDC	#3: BOOT
#1: COMP_W	#12: NULL	#4: TDO_MAIN
#2: COMP_V	#13: NULL	#5: TCK_MAIN
#3: COMP_U	#14: NULL	#6: TDI_MAIN
CNP901 : BLDC MOTOR	#15: NULL	#7: TMS_MAIN
#1: 310VDC	#16: NULL	#8: TRACECLK_MAIN
#2: NULL	#17: GND	#9: GND
#3: AGND	#18: DA_CLK	#10: 5VDC
#4: 15VDC	#19: DA_CS	#11: 5VDC
#5: MOTOR SIGNAL	#20: DA_DATA	#12: NULL
#6: FEEDBACK SIGNAL	CN810 : EEV	#13: NULL
CN470: THERMISTOR	#1: SIGNAL1	#14: TRACE3_MAIN
#1: OUT_TH	#2: SIGNAL2	#15: NULL
#2: GND	#3: SIGNAL3	#16: NULL
#3: DIS_TH	#4: SIGNAL4	#17: GND
#4: GND	#5: 12VDC	#18: TRACE2_MAIN
#5: COND_TH	CN700 : HEATER	#19: TRACE1_MAIN
#6: GND	#1: 12VDC	#20: TRACEO_MAIN
#7: OLP_TH	#2: GND	CN380 : DRED
#8: GND	#3: HEATER_N	#1: DRED1
CN800 : EEPROM	#4: HEATER_L	#2: DRED2
#1: GND	CNP031: 4WAY	#3: DRED3
#2: NULL	#1: AC	#4: GND
#3: 5VDC	#2: NULL	#5: 5VDC
#4: EEP_CS	#3: AC	
#5: EEP_SO		•
#6: EEP_SI		
	7	

## 7-4 DISPLAY PCB



CN1: DISPLAY	CN2: DETECT
#1: LED_DIO	#1:5V_1
#2: LED_CLK(DIS)	#2GND
#3: LED_RST(DIS)	#3:MDS_1
#4: POWER_SW	#4:MDS_2
#5:GND	
#6:5VDC	]
#7: REMOCON_INT(DIS)	1
#8: ADDRESS_SW(DIS)	1
#9: MAIN_RX(DIS_WIFI)	
#10: MAIN_TX(DIS_WIFI)	]
#11: WIFI_CONTROL(DIS_WIFI)	]
#12: 12VDC	]
#13: MDS_2(DIS_DETECT)	
#14: MDS_1(DIS_DETECT)	
#15: 5V_1	

### 7-5 Wire connecting the indoor unit terminal blocks

1. Terminal press of Ring terminal shall be set facing up before connecting wire.







Is inverted

Terminalhasbeencut.

2. There shall be no empty space between Ring terminal and Screw after Clamp.

If not, there exists a possibility of fire which can be caused by electric heat in the connecting part.













- ①, ②: Good
- ③ Bad : Ring terminal is connected reversely
- @ Bad : Not clamped Screw
- (5) Bad : In the gap between Ring terminal & Screw
- 6 Bad : Unused Ring Terminal

# 8. Operating Instructions


### 8-1 Name of Each Part

#### 8-1-1 Indoor Unit

The design and shape are subject to change according to the model.

#### Main Parts


#### AR\*\*CSDA\*\*\*\*



- 01 Air intake
- 02 Airfilter
- 03 WindFree panel
- 04 Airflow blade (up and down)

- 05 Airflow blade (left and right)
- 06 Power button/Remote control receiver
- 07 Room temperature sensor
- 08 Display

#### AR\*\*CSFC\*\*\*\*




- 01 Air intake
- 02 Airfilter
- 03 WindFree panel
- 04 Airflow blade (up and down)

- 05 Airflow blade (left and right)
- 06 Power button/Remote control receiver
- 07 Room temperature sensor
- 08 Display

## ◆ Display

#### AR\*\*CSDA\*\*\*\*



O1 Temperature indicator (numeric)
Filter reset indicator (¿f)
Electricity consumption indicator (numeric
/
For the multi-system, usage time indicator)


For the multi system, usage time indicator)
Auto clean indicator (¿;)
Defrost indicator (¿F)

- 02 Al Energy indicator
- 03 Al Auto indicator
- 04 Timer indicator good'sleep indicator
- 05 Wi-Fi indicator
- 06 Motion detect sensor

#### NOTE

• When the Wi-Fi is turned on, the indicator blinks three times and then turns on.

#### AR\*\*CSFC\*\*\*\*



O1 Temperature indicator (numeric)
Filter reset indicator (EF)
Electricity consumption indicator (numeric
/


For the multi system, usage time indicator)
Auto clean indicator (¿:)
Defrost indicator (¿F)

- 02 Al Energy indicator
- 03 Al Auto indicator
- 04 Timer indicator good'sleep indicator
- 05 Wi-Fi indicator

#### NOTE

 When the Wi-Fi is turned on, the indicator blinks three times and then turn on.

# 8-2 Wireless Remote control-Buttons and Display DB96-25318V



- 01 Set temperature indicator
- 02 Timer option indicator
- 03 Operation mode indicator
- 04 Options indicator
- 05 Low battery indicator
- 06 Transmit indicator
- 07 Fan speed indicator
- 08 WindFree indicator
- 09 Vertical air swing indicator
- 10 Horizontal air swing indicator
- 11 Power button
- 12 Temperature button
- 13 Timer button
- 14 Fan speed button
- 15 Direction button/Selection button
- 16 Vertical air swing button
- 17 Mode button
- 18 Fast/WindFree button
- 19 Horizontal air swing button
- 20 Options/Clean button
- 21 SET button/Temperature type button(°C↔°F)

#### NOTE

Although Purify, Direct, Indirect and Wash
 (\*\*07\*\*\*\*\*\*\* models) appear on the
 remote control display, they are not available
 on this model.

# 9. Troubleshooting

#### 9-1 Items to be checked first

- 1 The input voltage should be rating voltage ±10% range. The air conditioner may not operate properly if the voltage is out of this range.
- 2 Is the line cable linking the indoor unit and the outdoor unit linked properly? The indoor unit and the outdoor unit shall be linked by 5 cables. Check the terminals if the indoor unit and outdoor unit are properly linked by the same number of cables. Otherwise the air conditioner may not operate properly.
- 3 When a problem occurs due to the contents illustrated in the table below it is a symptom not related to the malfunction of the air conditioner.

NO.	Operation of air conditioner	Explanation	
1	The OPERATION indication LED(BLUE) blinks when a power plug of the indoor unit is plugged in for first time.	It indicates power is on. The LED stops blinking if the operation ON/OFF button on the remote control unit is pushed.	
2	In a COOL operation mode, the compressor does not operate at a room temperature higher than the setting temperature that the INDOOR FAN should operate.  [In case of heat pump model] In a HEAT operation mode, the compressor does not operate at a room temperature lower than the setting temperature that indoor fan should operate.	In happens after a delay of 3 minutes when the compressor is reoperated. The same phenomenon occurs when a power is on. As a phenomenon that the compressor is reoperated after a delay of 3 minutes, the indoor fan is adjusted automatically with reference to a temperature of the air blew.	
3	Fan speed setting is not allowed in DRY mode.	The speed of the indoor fan is set to LL in DRY mode. Fan speed is selected automatically in AUTO mode.	
4	Compressor stops operation intermittently in Dry mode.	Compressor operation is controlled automatically in DRY mode depending on the room temperature and humidity.	
5	Timer LED(ORANGE) of the indoor unit lights up and the air conditioner does not operate.	Timer is being activated and the unit is in ready mode. The unit operates normally if the timer operation is cancelled.	
6	The compressor stops intermittently in a COOL mode or DRY mode, and fan speed of the indoor unit decreases.	The compressor stops intermittently or the fan speed of the indoor unit decreases to prevent inside/outside air frozen depending on the inside/outside air temperature.	
7	[In case of heat pump model] Compressor of the outdoor unit is operating although it is turned off in a HEAT mode.	When the unit is turned off while de-ice is activated, the compressor continus operation for up to 9 minutes(maximum) until the deice is completed.	
8	[In case of heat pump model] The compressor and indoor fan stop intermittenly in HEAT mode.	The compressor and indoor fan stop intermittently if room temperature exceeds a setting temperature in order to protect the compressor from overheated air in a HEAT mode.	
9	[In case of heat pump model] Indoor fan and outdoor fan stop operation intermittently in a HEAT mode.	The compressor operates in a reverse cycle to remove exterior ice in a HEAT mode, and indoor fan and outdoor fan do not operate intermittently for within 20% of the total heater operation.	

#### 9-2 Communication Error

#### 9-2-1 Communication Error

#### Indoor display

7-SEG DISPLAY	DESCRIPTION
C101/C102	Communication error(Indoor<->outdoor)


#### **Outdoor display**

•	•	•	1min. Time out Comm.
0	0		Abnormal Communication
0			



#### 1. Checklist:

- 1) Is the cable between the indoor unit and outdoor unit connected correctly?
- 2) Isn't the power cable and communication cable cross?



#### 9-2-2 Indoor temperature sensor Error


#### Indoor display

7-SEG DISPLAY	DESCRIPTION
C121	Indoor room temp sensor error



#### 1. Checklist:

- 1) Is the indoor units temperature sensor connected correctly?
- 2) Is the sensor placed correctly?
- 3) Does the both terminal of sensor satisfy the resistance value in accordance with temperature?



#### 9-2-3 Indoor fan motor speed detecting error (BLDC fan)


#### Indoor display

7-SEG DISPLAY	DESCRIPTION
C154	Indoor fan error



#### 1. Checklist:

- 1) Is the indoor units fan motor properly connected with the connector(CN72)?
- 2) Is the AC voltage correct?



#### 9-2-4 Outdoor temperature sensor error

#### Indoor display


7-SEG DISPLAY	DESCRIPTION
C221	Outdoor temperature sensor error

#### **Outdoor display**



#### 1. Checklist:

- 1) Is the sensor connected correctly?
- 2) Is the sensor placed correctly?
- 3) Does the both terminal of sensor satisfy the resistance value in accordance with temperature?
- 4) Is the resistance value of sensor connection pull-up correct?



# 9-2-5 Outdoor Cond temperature sensor error

# Indoor display

7-SEG DISPLAY	DESCRIPTION
C231	Outdoor Cond temperature sensor error


# **Outdoor display**

	•	•	Outdoor Cond temperature sensor error
--	---	---	---------------------------------------



#### 1. Checklist:

- 1) Is the sensor connected correctly?
- 2) Is the sensor placed correctly?
- 3) Does the both terminal of sensor satisfy the resistance value in accordance with temperature?
- 4) Is the resistance value of sensor connection pull-up correct?



# 9-2-6 Outdoor Discharge temperature sensor error

# Indoor display

7-SEG DISPLAY	DESCRIPTION
C251	Outdoor Discharge temperature sensor error


# **Outdoor display**

•	•	0	Outdoor Discharge temperature sensor error

● LED ON U LED BLINKING O LED OFF

#### 1. Checklist:

- 1) Is the sensor connected correctly?
- 2) Is the sensor placed correctly?
- 3) Does the both terminal of sensor satisfy the resistance value in accordance with temperature?
- 4) Is the resistance value of sensor connection pull-up correct?



# 9-2-7 Operation condition secession error

# Indoor display


7-SEG DISPLAY	DESCRIPTION
C440	Prohibit Operation Condition Error (Heating)
C441	Prohibit Operation Condition Error (Cooling)

# **Outdoor display**

	•	0	Operation condition secession

#### 1. Checklist:

1) Check the temperature around the outdoor unit.



# 9-2-8 EEPROM error / OTP error

# Indoor display

7-SEG DISPLAY	DESCRIPTION
C470	EEPROM Data Error (no data)
C471	OTP errorEEPROM Data Error (Main Micom Inv Micom)


# **Outdoor display**

0	•	0	EEPROM Data Error (no data)
•	0	0	OTP errorEEPROM Data Error (Main Micomlnv Micom)



#### 1. Checklist:

- 1) Is there a short around micom?
- 2) Is there a short around "A"?
- 3) Did you download or insert EEPROM IC, after changing outdoor PBA?



#### 9-2-9 Outdoor Fan motor error

#### Indoor display


7-SEG DISPLAY	DESCRIPTION
C458	Outdoor fan error

# **Outdoor display**



LED ON LED BI 1. Checklist :

- 1 LED BLINKING O LED OFF
- 1) Are the input power voltage and the power connection correct?2) Is the motor wire connected to the outdoor PBA correctly?
  - 3) Is there no assembly error or non-assembly in the terminal of motor wire connector?
  - 4) Is there no obstacle at the surrounding of motor and propeller?



# 9-2-10 Compressor starting error

# Indoor display


7-SEG DISPLAY	DESCRIPTION
C461	Comp starting error

# **Outdoor display**

0	0	0	Comp starting error
---	---	---	---------------------

#### 1. Checklist:

- 1) Is the connection of cable for the compressor?
- 2) Is the compressor wire is connected clockwise? U(RED)-V(BLU)-W(YEL)
- 3) Is the interphase resistance of compressor normal?



# 9-2-11 Compressor wire missing error/rotation error

# Indoor display


7-SEG DISPLAY	DESCRIPTION
C467	Compressor wire missing errorr/rotation error

# **Outdoor display**

0	•	Compressor wire missing error/rotation error

#### 1. Checklist:

- 1) Is the connection of cable for the compressor?
- 2) Is the compressor wire is connected clockwise? U(RED)-V(BLU)-W(YEL)
- 3) Is the interphase resistance of compressor normal?



# 9-2-12 Current sensor error/Input current sensor error

# Indoor display

7-SEG DISPLAY	DESCRIPTION
C462	AC Input I_Limit Trip Error


# Outdoor display

			Current sensor error	
			Input current sensor error	

● LED ON ● LED BLINKING ● LED OFF

#### 1. Checklist:

- 1) Is the PFC Shunt("A") resistance value correct? Check the resistor is opened
- 2) Is the IPM Shunt("B") resistance value correct? Check the resistor is opened
- 3) Is there no short or open around "C"?



# 9-2-13 O.C(Over Current) error

# Indoor display

7-SEG DISPLAY	DESCRIPTION
C464	IPM Over Current(O.C) Error


# **Outdoor display**


O O © Current sensor error
----------------------------



#### 1. Checklist:

- 1) Is the IPM Shunt resistance value correct? Check the resistor is opened
- 2) Is the condition of surrounding temperature abnormal overload?
- 3) Is there any problem as like the temperature sensor separation or measurement value error?
- 4) Is the interphase resistance of compressor normal?






# 9-2-14 No power outdoor (Initial Diagnosis) (Not displayed)

#### 1. Checklist:


- 1) Is input power normal?
- 2) Is AC power linked correctly? (L,N,E)
- 3) Is mis-wiring between communication wire and Power wire?
- 4) Is mis-wiring between Main PBA and SMPS PBA wire?
- 5) Is input voltage of SMPS AC in Main PBA (CN150) normal?
- 6) Is the voltage of SMPS DC in Main PBA (CN151,CN152) normal?



# 9-2-15 When the Up/Down, Left/Right, Grill louver motor does not operate (Initial Diagnosis) (Not displayed)

#### 1. Checklist:


- 1) Is the input power voltage normal?
- 2) Is the Up/Down louver motor properly connected with the connector? (CN61, CN62, CN63)



# 9-2-16 When the remote control is not receiving

#### 1. Checklist:


- 1) Check if the connector was normally assembled.
- 2) Check the battery in remote control
- 3) All the lights out and check again: Change electronic typed to a rescent light
- 4) Put the set in operation and check the voltage of display PBA
- 5) Replace the display PBA



#### 9-2-17 Smart Install error


#### 1. Checklist:

- 1) Check the leakage region. (Use leakage detection liquid or soapy water)
- 2) When leakage region is found from service valve and piping connection re nut part : After the related measures to check the refrigerant supplements and operation.
- 3) If the leakage region is pipe welding part: Weld leakage region after refrigerant gas release.(Brass parts should only apply)
- 4) If the leakage region is surface area (Heat exchanger or pipe welding region is not): Replace parts.
- 5) Check the PBA Relay
- Display of indoor unit: Ensure that the operating pilot lamp has been lighted.
- Ensure that the Relay input voltage of indoor unit PBA is normally.(If the PBA is defective, replace)
- 2. When the air conditioner is in standby status, use the remote controller to start the Smart Install mode.
  - 1) Press the [SET], [Mode], [Power] button simultaneously for 4 seconds.
  - -Smart Install mode can be operated only with the supplied remote controller.
  - -During the Smart install mode procedure, remote controller cannot be operated.



# 9-2-18 Outdoor OLP over temperature error (One way Inverter Only)

#### Indoor display




### **Outdoor display**



● LED ON ● LED BLINKING ● LED OFF

# 1. Checklist :


- 1) Is the sensor placed correctly?
- 2) Check the service valve is closed
- 3) Check the compressor locking or gas leak



#### 9-2-19 EEV or VALVE CLOSE error (C422)


#### 1. failure cause

- 1) Check for leakage using leakage detection liquid or soapy water.
- 2) If a leak is found in the service valve or piping connection flare nut part, take the relevant action and recheck the refrigerant and operation.
- 3) If the leakage part is a PIPE welding part, rewelding is performed after release of refrigerant gas to block the leakage part.
- 4) If the leakage part is found on the surface other than the heat exchanger or PIPE welding part, replace the part
- 5) PBA Check
  - Check if an error has occurred in the indoor Dipslay.
  - Check if the input voltage of the indoor PBA is normal and replace the PBA if there is any abnormality.




# 10. Block Diagram

# 10-1 Indoor unit



# 10-2 Outdoor unit



#### 10-2-1 Pre-inspection Notices

- 1 Check if you pulled out the AC power plug when you eliminate the PCB or front panel.
- 2 Don't hold the PCB side not impose excessive force on it to eliminate the PCB.
- 3 Don't pull the lead wire but hold the whole housing to connect or disconnect a connector to the PCB.
- 4 In case of outdoor PCB disassembly, check first the complete discharge of condenser after 1 minute power off.

# 10-2-2 Inspection procedure

- 1 Check connector connection and peeling of PCB or bronze coating pattern when you think the PCB is broken.
- 2 The PCB is composed of 3 parts.
  - Indoor Main part : MICOM and surrounding circuit, relay, fan motor sensing and driving circuit, temperature sensing circuit power circuit of SMPS, buzzer circuit. Communication circuit.
  - Display part: LED lamp, Switch, Remote-control module.
  - Outdoor Main part: MICOM and surround circuit, fan motor sensing and driving circuit, compressor driving circuit power circuit of SMPS, PFC control circuit, 4way circuit, communication circuit, OPTION (EEV control circuit, temperature sensing circuit).

#### 10-2-3 Indoor detailed inspection procedure

No.	Procedure	Inspection Method	Cause
1	Plug out and pull the PCB out of the control box Check the PCB fuse	<ul><li>1) Is 1st fuse disconnected?</li><li>2) Is 2nd fuse disconnected?</li></ul>	<ul><li>Over current</li><li>Indoor Fan motor short</li><li>AC part and pattern short of Indoor PBA</li></ul>
	Supply power	Check the power voltage	
2	If the operating lamp twinkles at this time, the above 1)~3) have no relation	1) Is the BD71 input voltage 200Vac~240Vac?	<ul> <li>Power cord is fault, Fuse open, Wrong Power cable Wiring, AC part is faulty</li> </ul>
2	1)~5) Have no relation	2) Is the voltage between both terminal of ICO2 pin #1-#2 12Vdc?	Switching Trans of Power circuit is faulty
		3) Is the voltage between both terminal of ICO2 pin #2-#3 5Vdc?	Power circuit is faulty, Load short
	Press the ON/OFF button 1. Fan speed(high) 2. Continuous Operation	1) Is the voltage over AC 180V being imposed on terminal #3-#5 of fan motor connector (CN72)?	Fan motor of the indoor is faulty
3		2) The fan motor of the indoor unit doesn't run	Fan motor connector(CN72) is faulty
		3) The power voltage between terminal #3-#5 of the connector(CN72) is 0V	• PBA is faulty

# 10-2-4 Outdoor detailed inspection procedure


No.	Procedure	Inspection Method	Cause	
1	Plug out and pull the PCB out of the control box. Check the PCB fuse (Wait 3 minutes after power off)	1) Is 1st fuse disconnected?	<ul><li>Over current</li><li>AC part and pattern short of Outdoor PBA</li></ul>	
2	Check the Wiring	<ol> <li>1) Is the Compressor wire connected clockwise?</li> <li>2) Is the Reactor wire connected normal?</li> <li>3) Is the Fan wire connected normal?</li> <li>4) Is the 4way wire connected normal?</li> <li>5) Is the sensor wire connected normal?</li> <li>6) Is the EEV wire connected normal?</li> </ol>	<ul><li>Wrong assembly</li><li>Installation(service) condition is bad</li></ul>	
		Check the power voltage		
		1) Is the voltage between Terminal block L-N 200Vac~240Vac?	Power cord is faulty, Wrong Power cable Wiring	
		2) Is the C006 voltage 200Vac~240Vac?	<ul><li>Fuse open</li><li>.L,N,F1,F2 wire wrong wiring (Terminal Block-PBA)</li></ul>	
		3) Is the CN150 voltage 200Vac~240Vac?	<ul><li>Power circuit is faulty</li><li>Load short</li></ul>	
3	"Supply power and operate the set (Use Remote-con- trol, button in indoor set)"	4) Is the PFC050(#26-#27) voltage 200Vac~240Vac after 3 minutes later?	<ul> <li>Fuse open</li> <li>L,N,F1,F2 wire wrong wiring (Terminal Block-PBA)</li> <li>.PTC020 open</li> <li>.RY021, RY022 is faulty</li> <li>Outdoor Micom(IC201) error</li> </ul>	
3		5) Is the CE101 voltage 280Vdc~320dc after 3 minutes later?	<ul> <li>PFC050 is faulty</li> <li>Reactor wire is wrong connection</li> <li>Power circuit is faulty, Load short</li> <li>BLDC Fan motor error</li> </ul>	
		6) Is the voltage CN151 #1-#2 voltage 15Vdc?	<ul><li>Switching Trans of Power circuit is faulty</li><li>Load short</li></ul>	
		7) Is the voltage CN152 #1-#2 voltage 12Vdc?	<ul><li>Switching Trans of Power circuit is faulty</li><li>Load short</li></ul>	
		8) Is the voltage CN151 #3-#2 voltage 5Vdc?	<ul><li>Switching Trans of Power circuit is faulty</li><li>Load short</li></ul>	
4	Check the LED lamp display	1) Normal : RED on, GRN blink, YEL off 2) Abnormal - All o check no power - abnormal display : check error mode	<ul><li>F1,F2 wire wrong wiring</li><li>Outdoor PBA is faulty</li></ul>	

# 11. Reference Sheet

# 11-1 Low Refrigerant Pressure Distribution

**Note :** Please measure the refrigerant pressure after the air conditioner operates on testing cooling mode during more than 10 minutes.

■ Indoor Temp. Variation: 20°C ~ 32°C ■ Outdoor Temp. Variation: -5°C ~ 45°C



# 11-2 Pressure & Capacity mark

# ■ Power/Heat

W	cal/s	kcal/h	Btu/h	HP	kg.m/s	lb.m/s
1	0.23885	0.85985	3.4121	0.001341	0.10197	0.73756
4.1868	1	3.6	14.286	0.0056146	0.42693	3.088
1.163	0.27778	1	3.9683	0.0015596	0.11859	0.85778
0.29307	0.06999	0.252	1	3.9302x10 <sup>-4</sup>	0.029885	0.21616
745.7	178.11	641.19	2,544.4	1	76.04	550
9.8067	2.3423	8.4322	33.462	0.013151	1	7.233
1.3558	0.32383	1.0658	4.6262	0.0018182	0.13826	1

# 11-3 Q & A for Non-trouble

Classication	Class	Description		
Cooling	Q	The cooling is weak.		
	А	When it is hot outside, its cooling capacity decreases due to the increase of the ambient temperature. When the dust filter gets blocked or warm outside air gets in, the cooling capacity will decrease. So, make sure to clean the dust filter frequently, prevent heat loss by closing the doors and insulate the cooling area by using curtains, blinds, shades or window tinting.		
	Q	The cooling is good generally. But, it gets weak when it is considerably hot.		
	А	It occurs when the outdoor unit is exposed to direct sun light and heat-up air is not ventilated well. So,set up a sunblind over the outdoor unit and keep stu away from the unit to increase the ventilation. When the cooling capacity decreases during a heat wave, clean the heat exchanger of the outdoor unit or spray some cold water to the heat exchanger to increase the cooling capability.		
	Q	The cooling is weak. Does it need refrigerant charging?		
	А	It is not correct charging refrigerant regularly. Except that you have moved in several times or the connection pipes are broken, the refrigerant does not run low. So, when refrigerant is additionally charged, it could be costly and cause a product's failure. When the refrigerant leaks, all of it will escape in a short time resulting in cooling failure and no water coming out of the drain hose. So, if water comes out from the drain hose, it indicates the normal operation of the product and it does not need refrigerant charging.		
	Q	It fails to do cooling.		
	А	When the air conditioner is set to ventilation or the desired temperature is set higher than the current temperature, it fails to do cooling. In this case, select cooling or set the desired temperature lower.		
Leakage Q It oods the oor.		It oods the oor.		
	А	Place the drain hose properly. When it is not placed properly, the drain water would ow back ooding the oor. So, straighten out the drain hose for the water to be drained well.		
Q Water drips		Water drips at the drain connection (service valve) of the outdoor unit.		
	А	When a glass bottle is taken out of the refrigerator, moisture gets condensed on its surface due to the temperature dierences. The same principle applies to the air conditioner. When cold refrigerant goes through the copper tube, moisture gets condensed on the surface of the tube and the connection areas. To prevent the water condensation, the pipes are insulated. But, the connection areas of the outdoor unit are not insulated for the purpose of maintenance or repair, and water gets condensed due to the temperature dierences and drips down. Generally, it evaporates right away. But, when it drips much during muggy days, put a water pan on the oor.		
	Q	It leaks even though a drain pump is used.		
	А	It occurs when the drain pump is plugged out or it is out of order. Check the power of the drain pump and the position of the drain hose, and when the pump is faulty, contact the dra pump manufacturer. Samsung Electronics do not manufacture drain pumps. So, we are not able to correct the drain pump problems.		
Smells	Q	Whenever the air conditioner is turned on, it irritates my eyes and gives me a headache.		
	А	There are no components in the air conditioner irritating the eyes and sending out chemical smells. But, when the air conditioner is turned on, other smell sources are sucked into the air conditioner and get out of it. So find and root out the smell sources. Generally, it occurs at a interior renovated place, a pharmacy, a gasoline handling place, a tire shop, a second-hand book shop or an electronic component handling place, when its chemical or musty smells are sucked in and sent out, it can be misled that the air conditioner generates them.		

Classication	Class	Description		
Smells	Q	Whenever the air conditioner is turned on, it stinks.		
	A	When are no components in the air conditioner sending out chemical smells. But, when the air conditioner is turned on, other smell sources are sucked into the air conditioner and get out of it. So, find and root out the smell sources. Generally, when the drain hose is taken out to the washing room or there are sources of smells such as a diaper bin, a shoe shelf or a socks bin, bad smells generate. Also, it occurs where glass cleaners or air fresheners are used; when they are sucked in interacting with dusts and moistures inside, bad smells generate. these kinds of organic materials noxious to human bodies. So, we recommend against the use of them.		
	Q	Whenever the air conditioner is turned on, it smells sour.		
	A	When the room is papered recently, its paste smells would be sucked inside. Also, when the air conditioner is installed in the study room of young boys loving sweat-generating activities such as the basketball, excessive sweats evaporate and get sucked into the air conditioner resulting in bad smells. So, find and root out problem or refresh the room frequently.		
	Q	Whenever the air conditioner is turned on, it smells musty.		
	A	It is due to the improper keeping of the product after its use. When keeping the product, dry up the inside with the operation of ventilation to prevent must. When the product is kept without drying up the inside with ventilation, mold would grow inside resulting in must. So, open the windows and switch on the ventilation function to get rid of the saturated smell inside.		
	Q	Whenever the air conditioner is turned on, it sends out bad smells such as stale smells.		
	А	It occurs generally when there are pet animals in the house. Their smells stay at the same place. But, when the air conditioner is turned on, the air gets circulated resulting in the circulation of the smells. So, find and root out the problem or refresh the room frequently.		
	Q	It sends out bad smells.		
	А	When the air filter is filthy, it could send out bad smells. So, clean the filter and ventilate the room with the windows open while operating the ventilation function.		
Operation	Q	It won't start.		
	А	There is a power failure or it is plugged out. Also, check if the power distribution panel is switched o.		
	Q	It goes off during operation.		
	A	When the hot air does not escape properly, it goes o during operation. it occurs when it does not ventilate properly because the outdoor unit is covered, the back of the outdoor unit is blocked by a cardboard or a plywood panel, and the front of the outdoor unit is blocked by the closed window or other obstacles. Clear the above obstacles from the outdoor unit.		
	Q	It generally works properly. But, when it's considerably hot, it goes off during operation.		
	A	It occurs when the outdoor unit is exposed to direct sunlight and the hot air does not escape properly. Set up a sun blind over the outdoor unit and clear the neighboring obstacles from the outdoor unit to provide good ventilation. When it goes o frequently during a heat wave, it would prevent the turno and increase the cooling capacity cleaning the outdoor unit or spraying some water to the heat exchanger.		
	Q	The remote controller won't operate.		
	А	When the batteries run out or the transmitter or receiver of the remote controller is blocked by obstacles, change the batteries or keep the obstacles away from the controlling area. Also, the remote controller may mot work under intensive light from a 3-wave length lamp or a neon sign due to the EMI. In this case, take the remote controller closer to the receiver.		

Classication	Class	Description
Classication	Q	Who installs the air conditioner? (Relocation/Re-installation)
	A	When relocating or re-installing the air conditioner, make sure to contact Samsung Electronics Service Center or Authorized Service Agent and have them to do the job. (If not, it could cause personal injuryor product damage.) The cost for the relocation/re-installation of the air conditioner is subject to the customer's expense. There is a cost table. But, our service engineer needs to visit to total up the cost correctly. When you move in, make sure to contact Samsung Electronics Service Center or Authorized Service Agent in advance to streamline the process.
	Q	Is it possible to install the outdoor unit outside?
nearby side th		It is possible to install it at a designated place in the apartment or on the rooftop nearby. But, it's illegal hanging an angle iron case with the outdoor unit in it outside the apartment. Also, it is illegal obstructing passers-by with the outdoor unit installed outside.
	Q	What can be done to install the outdoor unit facing the road because it is a commercial building?
	A	The following is an excerpt from building code going into eect from JUNE 1 st 2005. "The exhaust pipe of a cooling or ventilation facility installed in a building adjacent to the streets of commercial or residential areas shall bel installed higher than 2 m to prevent the exhaust air from blowing directly to passersby and the current facilities shall be corrected by MAY 31 st 2005." So, please install it higher than 2 m or not to blow the hot exhausting air directly to passers-by.
	Q	What about installing a windscreen during installation not to blow hot air directly to passers-by?
	А	When the hot air from the front of the outdoor unit is blocked, the product's performance will be aected and it will fail to operate properly. So, keep it at least 300mm away from its surrounding walls and give it good ventilation.

# 11-4 Cleaning /Filter Change

#### Auto clean function

Use the Auto clean function if the indoor unit produces odors.

#### **Activating Auto clean**

To activate Auto clean, press the (Options) button for at least 3 seconds.

The indoor unit display shows:



If the air conditioner is off, Auto clean starts immediately. If the air conditioner is running, Auto clean starts as soon as the air conditioner turns off.

# NOTE


• You can also activate Auto clean from the Options menu:



- Once Auto clean is selected, it is always activated whenever the air conditioner turns off.
- Auto clean runs for 10 to up to 30 minutes depending on internal dry conditions. The indoor unit display shows the cleaning progress from 1% to 99%.
- If you start another function while Auto clean is progressing, Auto clean pauses and will resume when the other function stops.
- When Auto clean completes, the air conditioner turns off.

#### Canceling Auto clean

To cancel Auto clean while it is running, follow the procedure below:







# NOTE

• Canceling Auto clean does not deactivate it.

#### **Deactivating Auto clean**

To deactivate Auto clean, follow the procedure below while the air conditioner is in operation.





#### Cleaning the outside of the indoor unit


- 1 Turn off the air conditioner and wait until the fan stops.
- 2 Disconnect the power supply.
- 3 Use a soft brush or tepid damp cloth to clean the exterior.

# NARNING

 Do not clean the appliance by spraying water directly onto it. Water entering the unit may result in electric shock or fire that could cause death, serious injury, or property damage:

# **CAUTION**

- Do not use an alkaline detergent to clean the indoor unit display.
- Do not use sulphuric acid, hydrochloric acid, or organic solvents such as paint thinner, kerosene, acetone, benzene, or alcohol to clean the unit surfaces.



#### Cleaning the heat exchanger on the outdoor unit


- 1 Turn off the air conditioner and wait until the fan stops.
- 2 Disconnect the power supply.
- 3 Spray water on the heat exchanger to remove dust and other debris.

# **<u>^</u>** CAUTION

- Do not use sulphuric acid, hydrochloric acid, or organic solvents such as paint thinner, kerosene, acetone, benzene, or alcohol to clean the unit surfaces.
- If you need to inspect or clean the inside of the heat exchanger on the outdoor unit, contact a local service centre for help.

#### Cleaning the filter

Clean the air filter every two weeks or when the <code>rf</code> (filter-cleaning reminder) appears on the indoor unit display. The time between cleanings may vary, depending on the usage and environmental conditions.



- 1 Slide the filter off of the unit.
- 2 Use a soft brush or vacuum cleaner to remove any dust or debris on the filter.
- 3 Soak the filter in a solution of water and mild detergent for 30 minutes.
- 4 Rinse the filter and let it air dry in a well-ventilated area that is out of direct sunlight.
- 5 Reinstall the filter.
- 6 Reset the filter-cleaning reminder:



# **A** CAUTION

- Take care not to damage the filter during cleaning.
- Do not scrub the air filter with a hard-bristle brush or another cleaning utensil.
- Do not expose the air filter to direct sunlight when drying it.

#### 11-5 Installation

#### 11-5-1 Before Installation

Keep the air conditioner outlet and inlet free from its surroundings. In case of installation, keep the symmetry and fix it to prevent vibration. The pipe length shall meet the standard as far as possible.

#### 11-5-2 Installation Procedure

#### ■ Location

Install the product in an area to guarantee the best cooling eect, convenience of piping and electric work, and inexistence of vibration or wind.

#### ■ Wall Drilling

Drill the wall downward in a diameter of 60 to 65mm.

#### ■ Fixing Indoor Unit & Outdoor Unit


Fix the air conditioner indoor unit securely to the wall. Secure the outdoor unit in a suitable position.

#### ■ Pipe Spooling & Connectingt

You shall cut the pipe with a pipe cutter and grind all the burrs of the cut surface. pipe expansion may continue until the pipe surface becomes uneven or torn apart. Be sure to use a torque wrench to tighten pipes or are nuts.

<Torque & Depth>

Outer Diameter (D)	Torque(kgf-cm)	Depth(A)
ø6.35 mm(1/4")	140~170	1.3 mm
ø9.52 mm(3/8")	250~280	1.8 mm
ø12.70 mm(1/2")	380~420	2.0 mm
ø15.88 mm(5/8")	440~480	2.2 mm
ø19.05 mm(4/4")	9900~1,210	2.2 mm



#### ■ Leak Test

Put an inset gas like nitrogen in the outdoor unit pipe and put soap bubbles or other test liquids on the pipe surface for the leak test.

### ■ Drain Hose Connecting

Install the drain hose downward to drain water naturally. Be sure to pour water into the hose to check if it drains well.

#### ■ Electric & Earth Work

Electric and earth work shall meet the "Electric Facility Technology Standard" and the "Internal Wire Regulation" of the Electric Business Laws.

#### ■ Inspection & Trial Run

Upon completion of the tests, you shall make a trial run while you explain the main functions of the air conditioner to finish the installation.

# 11-6 Installation Diagram of Indoor Unit and Outdoor Unit

# 11-6-1 Air-Purge Procedure

1) Connect each assembly pipe to the appropriate valve on the outdoor unit and tighten the flare nut.



2) Connect the charging hose of low pressure side of manifold gauge to the packed valve having a service port (3/8" Packed valve) as shown at the figure.



3) Open the valve of the low pressure side of manifold gauge counter-clockwise.



- 4) Purge the air from the system using vacuum pump for about 30 minutes.
  - After that, please recheck that pressure is stabilized.
  - Close the valve of the low pressure side of manifold gauge clockwise.
  - Remove the hose of the low pressure side of manifold gauge.




5) Set valve cork of both liquid side and gas side of packed valve to the open position.





6) Mount the valve stem nuts to the 2 way and 3 way valve. And mount the service port cap to 3 way valve.



- 7) Check for gas leakage.
  - At this time, especially check for gas leakage from the 3 way valve's stem nuts, and from the service port cap.







#### 11-6-2 "Pump down" Procedure

Pump down will be carried out when an evaporator is replaced or when the unit is relocated in another area.

1) Remove the caps from the 3 way valve and the 3 way valve.



 Turn the 3 way valve clockwise to close and connect a pressure gauge (low pressure side) to the service valve, and open the 3 way valve again.



3) Set the unit to cool operation mode. (Check if the compressor is operating.)



4) Turn the 3 way valve clockwise to close.



5) When the pressure gauge indicates "0" turn the 3 way valve clockwise to close.



6) Stop operation of the air conditioner.



7) Close the cap of each valve.




#### Relocation of the air conditioner

- Refer to this procedure when the unit is relocated.
- Carry out the pump down procedure (refer to the details of 'pump down').
- Remove the power cord.
- Disconnect the assembly cable from the indoor and outdoor units.
- Remove the flare nut connecting the indoor unit and the pipe.
- At this time, cover the pipe of the indoor unit and the other pipe using a cap or vinyl plug to avoid foreign material entering.
- Disconnect the pipe connected to the outdoor unit.

At this time, cover the valve of the outdoor unit and the other pipe using a cap or vinyl plug to avoid foreign material entering.

- Make sure you do not bend the connection pipes in the middle and store together with the cables.
- Move the indoor and outdoor units to a new location.
- Remove the mounting plate for the indoor unit and move it to a new location.



# 11-7. Reference Sheet

# **Index for Model Name**

1st	2nd	3rd	4th	5th	6th	7th	8th	9th	10th	11th	12th	13th	14th
Pro	ject	Capa	acity	Sell	Fea	ture	Ser	ies	Со	lor	Unit	Exp	ort
Α	R	1	2	С	S	D	Α	В	W	K	N/X	С	V

Item	1st	2nd
RAC	Α	R

Item	Reference	3rd	4th
1	Export	1	0
2	Export	1	3
3	Export	1	8
4	4 Export		4

Item	5th	Item	6th
20 Year	Т	INVERTER HP R32	Χ
21 Year	Α	INVERTER CO R32	Υ
22 Year	В	INVERTER HP R-410A	S
23 Year	С	INVERTER CO R-410A	V

Item	7th
Motion detact + PM1.0 Filter + PM1.0 Sensor + Wifi	А
Motion detact + PM1.0 Filter + Wifi	В
Motion detact + Wifi + Tri-care filter	С
Motion detact + Wifi	D
Wifi + Tri-care filter	Е
Wifi	F
Tri-care filter	G
none	Н
Good1,swing	J

Item	8th
WindFree GEO	А
WindFree AIRISE	С
Wind GEO	Υ
Wind AIRISE	Z

Item	9th		
1ST MODEL	Α		
2nd MODEL	В		
18 th Model	R		

Division	Series	Project	Color Name	Division component	Sinkeolreo code (10th,11th)	Remark
	А	GEO (WindFree)	DA White	Grille	WK	
OMD	С	AIRISE (WindFree)	DA White	Grille	WK	
QMD	Υ	GEO (Wind)	DA White	Grille	WK	
	Z	AIRISE (Wind)	DA White	Grille	WK	

Item	12th
SET	/
IN	N
OUT	X

The existing code	The sales area	CIS Desription	The integrated code (13th,14th)
CV	AMERICA	KCV	CV

# **SAMSUNG**

# **ELECTRONICS**

# **GSPN (GLOBAL SERVICE PARTNER NETWORK)**

Area	Web Site
North America	http://gspn3.samsungcsportal.com
Latin America	http://gspn3.samsungcsportal.com
CIS	http://gspn1.samsungcsportal.com
Europe	http://gspn1.samsungcsportal.com
China	http://china.samsungportal.com
Asia	http://gspn2.samsungcsportal.com
Middleeast & Africa	http://gspn1.samsungcsportal.com

This Service Manual is a property of Samsung Electronics Co., Ltd. Any unauthorized use of Manual can be punished under applicable International and/or domestic law.

© Samsung Electronics Co., Ltd. August 2023