


RXS24LVJU Wiring Diagram



Z1C~Z6C : FERRITE CORE
 X1W, X2W : TERMINAL STRIP
 Y1E : ELECTRONIC EXPANSION VALVE COIL
 V2, V3, V5, V9, V100 : VARIATOR
 SA2 : SURGE ABSORBER
 FU1, FU2, FU3 : FUSE
 AC1, AC2 :
 U, V, W, X11A :
 E1, E2 :
 HR1, HR2 : CONNECTOR

MRW10, MRW20 :
 MRC/W, MR30 : MAGNETIC RELAY
 R1T~R3T : THERMISTOR
 S2~S102 : CONNECTOR
 LED A : PILOT LAMP

L1, L2 : LIVE
 SW1 : FORCED COOLING OPERATION SWITCH(SW1)
 SW4 : LOCAL SETTING SW (SW4)

M1C : COMPRESSOR MOTOR
 M1F : FAN MOTOR
 L1R : REACTOR
 Q1L : OVERLOAD PROTECTOR
 PM1 : POWER MODULE
 PCB1, 2 : PRINTED CIRCUIT BOARD
 Y1S : REVERSING SOLENOID VALVE COIL
 SHEET METAL : TERMINAL STRIP FIXED PLATE
 GR : PROTECTIVE GROUND
 ⏏ : GROUND